

RX Family

DTC Module Using Firmware Integration Technology

Introduction

This application note describes the Data Transfer Controller (DTC) module which uses Firmware Integration Technology (FIT). This module uses DTC to control data transfer process using DTC software module. In this document, this module is referred to as the DTC FIT module.

Target Devices

- RX110 Group, RX111 Group, RX113 Group, RX130 Group, RX13T Group, RX140 Group
- RX230 Group, RX231 Group, RX23T Group, RX24T Group, RX24U Group
- RX23W Group
- RX23E-A Group
- RX64M Group, RX65N Group, RX651 Group, RX66T Group, RX66N Group, RX671 Group
- RX71M Group
- RX72T Group
- RX72M Group, RX72N Group

When using this application note with other Renesas MCUs, careful evaluation is recommended after making modifications to comply with the alternate MCU.

Target Compilers

- Renesas Electronics C/C++ Compiler Package for RX Family
- GCC for Renesas RX
- IAR C/C++ Compiler for Renesas RX (RX13T not supported)

For details of the confirmed operation contents of each compiler, refer to "6.1 Confirmed Operation Environment".

Contents

1. Overview	4
1.1 DTC FIT Module	4
1.2 Overview of DTC FIT Module	4
1.3 Using the FIT DTC module.....	6
1.3.1 Using FIT DTC module in C++ project.....	6
1.4 API Overview.....	6
1.5 DTC IP Version.....	7
2. API Information.....	8
2.1 Hardware Requirements	8
2.2 Software Requirements.....	8
2.3 Limitations	8
2.3.1 RAM Location Limitations.....	8
2.4 Supported Toolchain	8
2.5 Interrupt Vector	8
2.6 Header Files	9
2.7 Integer Types.....	9
2.8 Configuration Overview	10
2.9 Code Size	11
2.10 Parameters	15
2.10.1 r_dtc_rx_if.h.....	15
2.10.2 r_dtc_rx_target_if.h	16
2.11 Return Values	17
2.12 Callback function.....	17
2.13 Adding the FIT Module to Your Project.....	18
2.14 “for”, “while” and “do while” statements.....	19
3. API Functions	20
R_DTC_Open().....	20
R_DTC_Close()	21
R_DTC_Create().....	23
R_DTC_CreateSeq()	31
R_DTC_Control().....	38
R_DTC_GetVersion().....	43
4. Pin Setting	43
5. Demo Projects.....	44
5.1 dtc_demo_rskrx231, dtc_demo_rskrx231_gcc.....	44
5.2 dtc_demo_rskrx65n_2m, dtc_demo_rskrx65n_2m_gcc	44
5.3 dtc_demo_rskrx130, dtc_demo_rskrx130_gcc.....	44

5.4	dtc_demo_rskrx72m, dtc_demo_rskrx72m_gcc.....	44
5.5	dtc_demo_rskrx671, dtc_demo_rskrx671_gcc.....	44
5.6	Adding a Demo to a Workspace	44
5.7	Downloading Demo Projects	44
6.	Appendices.....	45
6.1	Confirmed Operation Environment	45
6.2	Troubleshooting	53
7.	Reference Documents	54
	Related Technical Updates	54
	Revision History	55

1. Overview

1.1 DTC FIT Module

The DTC FIT module can be used by being implemented in a project as an API. See section 2.13, Adding the FIT Module to Your Project for details on methods to implement this FIT module into a project.

1.2 Overview of DTC FIT Module

The DTC FIT module supports 3 transfer modes:

- Normal transfer mode
- Repeat transfer mode
- Block transfer mode

Each mode can enable Chain transfer and Sequence transfer functionality or not. For additional details, see the “Data Transfer Controller” section of the User’s Manual: Hardware.

The DTC is activated by interrupt requests from interrupt sources. The user should create transfer information corresponding to each activation source or many consecutive information elements in the case of chain transfers. Transfer information consists of a start address for source and destination and, configuration information controlling how the DTC will transfer the data. When the DTC is activated, it will read the corresponding Transfer information and start the transfer.

DTC reads start address of a Transfer data that belongs to a specified interrupt source in DTC Vector table. This Vector table is an array of 4 byte addresses and start address of Transfer data (n) that belong to interrupt source with vector number (n) will be stored at the row of table (element of array) having index (4 * n).




Figure 1.1 DTC Vector and Transfer Information

The user must allocate a memory space for DTC Vector table on RAM area before using DTC and the size (in byte units) of allocated memory depends on the maximum vector number value of interrupt sources supported by DTC and it is specified by `equate DTC_VECTOR_TABLE_SIZE_BYTES` defined in file `r_dtc_rx_target.h` for each MCU in "targets" folder; this default value is a value which supports all available activation source define in Interrupt Vector Table (For example, if it is RX111, it is $0x3E4$ ($0x3E4 = 249 * 4$). if it is RX64M, it is $0x400$ ($0x400 = 256 * 4$).). The start address of DTC Vector table must be in 1-Kbyte units and user may also use the Linker to allocate Vector table at compilation time.

The DTC can work on 2 address modes: short mode and full mode. In short mode, the size of one Transfer data is 3 long words (12 bytes) and DTC can access to a 16-Mbyte memory space in the range $0x00000000$ to $0x007FFFFFFF$ and $0xFF800000$ to $0xFFFFFFFF$. In full mode, the size of one Transfer data is 4 long words (16 bytes) and DTC can access to a 4-Gbyte memory space ($0x00000000$ to $0xFFFFFFFF$).

By default, DTC will read Transfer data whenever an activation interrupt is raised. When there are 2 or many continuous active times just caused by an activation source, the user can skip the read process from the moment of second activation time to increase the performance of DTC because the content of Transfer data is already existed in DTC from the previous active time. To enable the Transfer Data Read Skip, the user can configure at initialization time by `R_DTC_Open()` or can use `R_DTC_Control()` with command `DTC_CMD_DATA_READ_SKIP_ENABLE`.

To initialize DTC, the `R_DTC_Open()` is called. This function will start supplying clock to DTC, and write the start address of DTC vector table to DTC Vector Base Register (DTCVBR). When using the sequence transfer, DTC index table address is written to DTC index table base register (DTCIBR). Also the function initializes the settings for Transfer Data Read Skip, DTC address mode and the DTCER registers corresponding to the configuration selections of user in `r_dtc_rx_config.h`.

The users shall provide configuration selections to `R_DTC_Create()` function to create Transfer data corresponding to a specific interrupt source. A Transfer data contains start address of source and destination and configuration information about how DTC will transfer data content from source to destination area. In `R_DTC_Create()`, the start address of Transfer data is stored in DTC vector table at the row according with the input vector number.

`R_DTC_CreateSeq()` creates the transfer information for sequence transfer and stores the start address of the transfer information at the specified location of the sequence number in DTC index table.

The `R_DTC_Control()` is used to select (or deselect) an interrupt as a DTC activation source, start or stop supplying clock to DTC, enable or disable Transfer Data Read Skip, abort the current chain transfer process, and enable or disable or abort the sequence transfer.

DTC is active when the activation source raises an interrupt. It will read the Transfer data corresponding to the vector number of activation interrupt to self-configure, and then transfer the data. Users can also use `R_DTC_Control()` to get the current status of DTC: whether DTC is in progress, the vector number of current active interrupt. The driver also support aborting the current Chain transfer process and sequence transfer process via `R_DTC_Control()` function.

Usage Conditions of DTC FIT Module

The usage conditions of the module are as follows.

- The `r_bsp` default lock function must be used.
- A single common bit must be used as the DMAC module stop setting bit and the DTC module stop setting bit.

1.3 Using the FIT DTC module

1.3.1 Using FIT DTC module in C++ project

For C++ project, add FIT DTC module interface header file within extern "C":

```
Extern "C"
{
    #include "r_smc_entry.h"
    #include "r_dtc_rx_if.h"
}
```

1.4 API Overview

Table 1.1 lists the API functions included in this module.

Table 1.1 API Functions

Function Name	Description
<code>R_DTC_Open()</code>	Initialization Processing
<code>R_DTC_Close()</code>	End Processing
<code>R_DTC_Create()</code>	Register and Activation Source Setting Processing
<code>R_DTC_CreateSeq()</code>	Register and Activation Source Setting Processing for sequence transfer
<code>R_DTC_Control()</code>	Operation Setting Processing
<code>R_DTC_GetVersion()</code>	Version Information Acquisition Processing

1.5 DTC IP Version

Table 1.2 lists relations about the DTC IP Version and target device.

The argument specifications of R_DTC_Create() function and the R_DTC_CreateSeq() function variable for the difference in DTC IP version. Refer to 3, API Functions.

Table 1.2 Lists of DTC IP Version

DTC IP Version	Target Device
DTCa	RX110 Group, RX111 Group, RX113 Group, RX130 Group RX230 Group, RX231 Group, RX23T Group, RX23W Group, RX23E-A Group, RX24T Group, RX24U Group RX64M Group, RX66T Group RX71M Group, RX72T Group
DTCb	RX65N Group, RX66N Group, RX72M Group, RX72N Group, RX13T Group, RX671 Group, RX140 Group

2. API Information

This FIT module has been confirmed to operate under the following conditions.

2.1 Hardware Requirements

The MCU used must support the following functions:

- DTC (DTCa or DTCb)
- ICU

2.2 Software Requirements

This driver is dependent upon the following FIT module:

- Renesas Board Support Package (r_bsp) v5.20 or higher

2.3 Limitations

2.3.1 RAM Location Limitations

In FIT, if a value equivalent to NULL is set as the pointer argument of an API function, error might be returned due to parameter check. Therefore, do not pass a NULL equivalent value as pointer argument to an API function.

The NULL value is defined as 0 because of the library function specifications. Therefore, the above phenomenon would occur when the variable or function passed to the API function pointer argument is located at the start address of RAM (address 0x0). In this case, change the section settings or prepare a dummy variable at the top of the RAM so that the variable or function passed to the API function pointer argument is not located at address 0x0.

In the case of the CCRX project (e2 studio V7.5.0), the RAM start address is set as 0x4 to prevent the variable from being located at address 0x0. In the case of the GCC project (e2 studio V7.5.0) and IAR project (EWRX V4.12.1), the start address of RAM is 0x0, so the above measures are necessary.

The default settings of the section may be changed due to the IDE version upgrade. Please check the section settings when using the latest IDE.

2.4 Supported Toolchain

This driver has been confirmed to work with the toolchain listed in 6.1, Confirmed Operation Environment.

2.5 Interrupt Vector

The DTC interrupt is enabled by executing the R_DTC_Create() function or the R_DTC_CreateSeq() (with specified condition) (while the macro definition DTC is 1).

Table 2.1 lists the interrupt vector used in the DTC FIT Module.

Table 2.1 DTC Interrupt vector

Interrupt timing	struct member	
When data transfer a specified number of times finished, Interrupt occurs to CPU.	response_interrupt	DTC_INTERRUPT_AFTER_ALL_COMPLETE
Every time data transfer, Interrupt occurs to CPU.		DTC_INTERRUPT_PER_SINGLE_TRANSFER

2.6 Header Files

All API calls and their supporting interface definitions are located in `r_dtc_rx_if.h`.

`r_dtc_rx_target.h` file should be included by User's application, when allocating a memory space for DTC Vector table on RAM area using `DTC_VECTOR_TABLE_SIZE_BYTES` definition.

2.7 Integer Types

This project uses ANSI C99. These types are defined in `stdint.h`.

2.8 Configuration Overview

The configuration option settings of this module are located in `r_dtc_rx_config.h`. The option names and setting values are listed in the table below:

Configuration options in <code>r_dtc_rx_config.h</code>	
DTC_CFG_PARAM_CHECKING_ENABLE Note: The default value is the value of <code>BSP_CFG_PARAM_CHECKING_ENABLE</code> in the <code>r_bsp_config.h</code> file.	SPECIFY WHETHER TO INCLUDE CODE FOR API PARAMETER CHECKING 0: Compiles out parameter checking. 1: Includes parameter checking. Default value is set to <code>BSP_CFG_PARAM_CHECKING_ENABLE</code> to re-use the system default setting.
DTC_CFG_DISABLE_ALL_ACT_SOURCE Note: The default value is "DTC_ENABLE".	SPECIFY WHETHER THE DTCER REGISTERS WILL BE CLEARED IN <code>R_DTC_OPEN()</code> DTC_DISABLE: Do nothing. DTC_ENABLE: Clear all DTCER registers in <code>R_DTC_Open()</code> .
DTC_CFG_SHORT_ADDRESS_MODE Note: The default value is "DTC_DISABLE".	SPECIFY WHICH ADDRESS MODE IS SUPPORTED BY DTC DTC_DISABLE: Select the Full-address mode. DTC_ENABLE: Select the Short-address mode.
DTC_CFG_TRANSFER_DATA_READ_SKIP_EN Note: The default value is "DTC_ENABLE".	SPECIFY WHETHER THE TRANSFER DATA READ SKIP IS ENABLED DTC_DISABLE: Disable Transfer Data Read Skip. DTC_ENABLE: Enable Transfer Data Read Skip.
DTC_CFG_USE_DMAC_FIT_MODULE Note: The default value is "DTC_ENABLE".	SPECIFY WHETHER THE DMAC FIT MODULE IS USED WITH DTC FIT MODULE DTC_DISABLE: DMAC FIT module is not used with DTC FIT module. DTC_ENABLE: DMAC FIT module is used with DTC FIT module. When DMAC FIT module is not used and "DTC_ENABLE" is set, the compiling error will be generated.
DTC_CFG_USE_SEQUENCE_TRANSFER Note: The default value is "DTC_DISABLE".	SPECIFY WHETHER THE SEQUENCE TRANSFER IS USED. DTC_DISABLE: SEQUENCE TRANSFER is not used. DTC_ENABLE: SEQUENCE TRANSFER is used. When defined as "DTC_ENABLE", set <code>DTC_CFG_SHORT_ADDRESS_MODE</code> to "DTC_DISABLE". When defined both this definition and <code>DTC_CFG_SHORT_ADDRESS_MODE</code> as "DTC_ENABLE", the compiling error will be generated. When defined as "DTC_ENABLE" for the MCU not supporting sequence transfer, the compiling error will be generated as well.

2.9 Code Size

Typical code sizes associated with this module are listed below.

The ROM (code and constants) and RAM (global data) sizes are determined by the build-time configuration options described in 2.8, Configuration Overview. The table lists reference values when the C compiler's compile options are set to their default values, as described in 2.4, Supported Toolchain. The compile option default values are optimization level: 2, optimization type: for size, and data endianness: little-endian. The code size varies depending on the C compiler version and compile options.

ROM, RAM, and Stack Code Sizes							
Device	Category	Memory Used					
		Renesas Compiler		GCC		IAR Compiler	
RX111	ROM	1207 bytes		2680 bytes		2235 bytes	
	RAM	9 bytes +2,024 bytes (Note5, 6)		8 bytes +2,024 bytes (Note5, 6)		1044 bytes +2,024 bytes (Note5, 6)	
	Max. user stack	60 bytes		-		24 bytes	
	Max. interrupt stack	-		-		-	
RX231	ROM	1445 bytes		2948 bytes		2223 bytes	
	RAM	9 bytes +2,024 bytes (Note5, 6)		8 bytes +2,024 bytes (Note5, 6)		1044 bytes +2,024 bytes (Note5, 6)	
	Max. user stack	60 bytes		-		24 bytes	
	Max. interrupt stack	-		-		-	
RX23W	ROM	1413 bytes		-	-	-	-
	RAM	9 bytes + 2,024 bytes (Note5, 6)					
	Max. user stack	60 bytes					
	Max. interrupt stack	-					
RX23E-A	ROM	1365 bytes		6476 bytes		2137 bytes	
	RAM	9 bytes + 2,024 bytes (Note5, 6)		2168 bytes + 2,024 bytes (Note5, 6)		1045 bytes + 2,024 bytes (Note5, 6)	
	Max. user stack	64 bytes		-		56 bytes	
	Max. interrupt stack	-		-		-	
RX65N	ROM	1966 bytes (Note6)	2159 bytes (Note7)	3540 bytes (Note6)	3892 bytes (Note7)	2672 bytes (Note6)	2892 bytes (Note7)
	RAM	9 bytes +2,048 bytes (Note5, 6)	9 bytes +3,072 bytes (Note5, 7)	12 bytes +2,048 bytes (Note5, 6)	12 bytes +3,072 bytes (Note5, 7)	1045 bytes +2,048 bytes (Note5, 6)	1045 bytes +3,072 bytes (Note5, 7)
	Max. user stack	64 bytes	64 bytes	-	-	172 bytes	176 bytes
	Max. interrupt stack	-	-	-	-	-	-
RX66T	ROM	1515 bytes (Note6)		3576 bytes (Note6)		2359 bytes (Note6)	
	RAM	9 bytes +2,048 bytes (Note5, 6)		12 bytes +2,048 bytes (Note5, 6)		1045 bytes +2,048 bytes (Note5, 6)	
	Max. user stack	60 bytes		-		24 bytes	
	Max. interrupt stack	-		-		-	

RX66N	ROM	1988 bytes (Note6)	2171 bytes (Note7)	7220 bytes (Note6)	7604 bytes (Note7)	2409 bytes (Note6)	2633 bytes (Note7)
	RAM	9 bytes +2,048 bytes (Note5, 6)	9 bytes +3,072 bytes (Note5, 7)	2208 bytes +2,048 bytes (Note5, 6)	2208 bytes +3,072 bytes (Note5, 7)	1045 bytes +2,048 bytes (Note5, 6)	1045 bytes +3,072 bytes (Note5, 7)
	Max. user stack	52 bytes	52 bytes	-		60 bytes (Note6)	60 bytes (Note7)
	Max. interrupt stack	-	-	-		-	
RX71M	ROM	1873 bytes		4392 bytes		2430 bytes	
	RAM	9 bytes +2,048 bytes (Note5, 6)		12 bytes +2,048 bytes (Note5, 6)		1045 bytes +2,048 bytes (Note5, 6)	
	Max. user stack	60 bytes		-		24 bytes	
	Max. interrupt stack	-		-		-	
RX72T	ROM	1,515 bytes		3076 bytes		2363 bytes	
	RAM	9 bytes +2,048 bytes (Note5, 6)		12 bytes +2,048 bytes (Note5, 6)		1045 bytes +2,048 bytes (Note5, 6)	
	Max. user stack	60 bytes		-		24 bytes	
	Max. interrupt stack	-		-		-	
RX72M	ROM	1932 bytes (Note6)	2115 bytes (Note7)	7204 bytes (Note6)	7588 bytes (Note7)	2557 bytes (Note6)	2781 bytes (Note7)
	RAM	9 bytes +2,048 bytes (Note5, 6)	9 bytes +3,072 bytes (Note5, 7)	68 bytes +2,048 bytes (Note5, 6)	68 bytes +3,072 bytes (Note5, 7)	1045 bytes +2,048 bytes (Note5, 6)	1045 bytes +3,072 bytes (Note5, 7)
	Max. user stack	64 bytes	64 bytes	-		180 bytes (Note6)	176 bytes (Note7)
	Max. interrupt stack	-	-	-		-	
RX72N	ROM	1988 bytes (Note6)	2172 bytes (Note7)	7220 bytes (Note6)	7602 bytes (Note7)	2407 bytes (Note6)	2631 bytes (Note7)
	RAM	9 bytes +2,048 bytes (Note5, 6)	9 bytes +3,072 bytes (Note5, 7)	2172 bytes +2,048 bytes (Note5, 6)	2172 bytes +3,072 bytes (Note5, 7)	1045 bytes +2,048 bytes (Note5, 6)	1045 bytes +3,072 bytes (Note5, 7)
	Max. user stack	52 bytes	52 bytes	-		60 bytes (Note6)	60 bytes (Note7)
	Max. interrupt stack	-	-	-		-	

RX13T	ROM	1356 bytes (Note6)	1550 bytes (Note7)	6552 bytes (Note6)	6936 bytes (Note7)	-	-
	RAM	9 bytes +2,048 bytes (Note5, 6)	9 bytes +3,072 bytes (Note5, 7)	2172 bytes +2,048 bytes (Note5, 6)	2172 bytes +3,072 bytes (Note5, 7)	-	-
	Max. user stack	64 bytes	64 bytes	-	-	-	-
	Max. interrupt stack	-	-	-	-	-	-
RX671	ROM	1988 bytes (Note6)	2172 bytes (Note7)	7220 bytes (Note6)	7602 bytes (Note7)	2407 bytes (Note6)	2631 bytes (Note7)
	RAM	9 bytes +2,048 bytes (Note5, 6)	9 bytes +3,072 bytes (Note5, 7)	2172 bytes +2,048 bytes (Note5, 6)	2172 bytes +3,072 bytes (Note5, 7)	1045 bytes +2,048 bytes (Note5, 6)	1045 bytes +3,072 bytes (Note5, 7)
	Max. user stack	52 bytes	52 bytes	-	-	60 bytes (Note6)	60 bytes (Note7)
	Max. interrupt stack	-	-	-	-	-	-
RX140	ROM	1409 bytes (Note6)	1589 bytes (Note7)	6644 bytes (Note6)	7028 bytes (Note7)	2223 bytes (Note6)	2447 bytes (Note7)
	RAM	9 bytes +2,048 bytes (Note5, 6)	9 bytes +3,072 bytes (Note5, 7)	64 bytes +2,048 bytes (Note5, 6)	64 bytes +3,072 bytes (Note5, 7)	1045 bytes +2,048 bytes (Note5, 6)	1045 bytes +3,072 bytes (Note5, 7)
	Max. user stack	52 bytes	52 bytes	-	-	56 bytes (Note6)	56 bytes (Note7)
	Max. interrupt stack	-	-	-	-	-	-

Note 1 The memory sizes listed apply when the default settings listed in 2.8, "Configuration Overview", are used. The memory sizes differ according to the definitions selected.

Note 2 Under confirmation conditions listed the following.

- r_dtc_rx.c
- r_dtc_rx_target.c

Note 3 The required memory sizes differ according to the C compiler version and the compile conditions.

Note 4 The memory sizes listed apply when the little endian. The above memory sizes also differ according to endian mode.

Note 5 The DTC FIT module secures the memory required for the DTC Vector table and the DTC index table using the malloc() function. For this memory size, refer to #define DTC_VECTOR_TABLE_SIZE_BYTES in r_dtc_rx_target.h.

Note 6 Only when DTC_CFG_USE_SEQUENCE_TRANSFER set DTC_DISABLE.

Note 7 Only when DTC_CFG_USE_SEQUENCE_TRANSFER set DTC_ENABLE.

2.10 Parameters

This section describes the parameter structure used by the API functions in this module. The structure is located in `r_dtc_rx_if.h` as are the prototype declarations of API functions.

2.10.1 `r_dtc_rx_if.h`

```
/* Short-address mode */
typedef struct st_transfer_data { /* 3 long words */
    uint32_t lw1;
    uint32_t lw2;
    uint32_t lw3;
} dtc_transfer_data_t;

/* Full-address mode */
typedef struct st_transfer_data { /* 4 long words */
    uint32_t lw1;
    uint32_t lw2;
    uint32_t lw3;
    uint32_t lw4;
} dtc_transfer_data_t;

/* Transfer data configuration */
/* Moved struct dtc_transfer_data_cfg_t to r_dtc_rx_target_if.h */

typedef enum e_dtc_command {
    DTC_CMD_DTC_START,          /* DTC will accept activation requests. */
    DTC_CMD_DTC_STOP,          /* DTC will not accept new activation request. */
    DTC_CMD_ACT_SRC_ENABLE,     /* Enable an activation source specified by vector number. */
    DTC_CMD_ACT_SRC_DISABLE,    /* Disable an activation source specified by vector number. */
    DTC_CMD_DATA_READ_SKIP_ENABLE, /* Enable Transfer Data Read Skip. */
    DTC_CMD_DATA_READ_SKIP_DISABLE, /* Disable Transfer Data Read Skip. */
    DTC_CMD_STATUS_GET,         /* Get the current status of DTC. */
    DTC_CMD_CHAIN_TRANSFER_ABORT /* Abort the current Chain transfer process. */

    DTC_CMD_SEQUENCE_TRANSFER_ENABLE /* Enable sequence transfer */
    DTC_CMD_SEQUENCE_TRANSFER_DISABLE /* Disable Sequence transfer */
    DTC_CMD_SEQUENCE_TRANSFER_ABORT /* Abort sequence transfer */
} dtc_command_t;
```

2.10.2 r_dtc_rx_target_if.h

dtc_transfer_data_cfg_t has different definition according to DTC IP Version.

1. DTCa

```
typedef struct st_dtc_transfer_data_cfg {
    dtc_transfer_mode_t    transfer_mode;    /* DTC transfer mode */
    dtc_data_size_t       data_size;        /* Size of data */
    dtc_src_addr_mode_t    src_addr_mode;    /* Address mode of source */
    dtc_chain_transfer_t   chain_transfer_enable;
                                /* Chain transfer is enabled or not */
    dtc_chain_transfer_mode_t chain_transfer_mode;
                                /* How chain transfer is performed */
    dtc_interrupt_t        response_interrupt;
                                /* How response interrupt is raised */
    dtc_repeat_block_side_t repeat_block_side; /* Side being repeat or block */
    dtc_dest_addr_mode_t   dest_addr_mode;    /* Address mode of destination */
    uint32_t               source_addr;       /* Start address of source */
    uint32_t               dest_addr;        /* Start address of destination */
    uint32_t               transfer_count;    /* Transfer count */
    uint16_t               block_size;
                                /* Size of a block in block transfer mode */
    uint16_t               rsv;              /* Reserve bit */
} dtc_transfer_data_cfg_t;
```

2. DTCb

```
typedef struct st_dtc_transfer_data_cfg {
    dtc_transfer_mode_t    transfer_mode;    /* DTC transfer mode */
    dtc_data_size_t       data_size;        /* Size of data */
    dtc_src_addr_mode_t    src_addr_mode;    /* Address mode of source */
    dtc_chain_transfer_t   chain_transfer_enable;
                                /* Chain transfer is enabled or not */
    dtc_chain_transfer_mode_t chain_transfer_mode;
                                /* How chain transfer is performed */
    dtc_interrupt_t        response_interrupt;
                                /* How response interrupt is raised */
    dtc_repeat_block_side_t repeat_block_side; /* Side being repeat or block */
    dtc_dest_addr_mode_t   dest_addr_mode;    /* Address mode of destination */
    uint32_t               source_addr;       /* Start address of source */
    uint32_t               dest_addr;        /* Start address of destination */
    uint32_t               transfer_count;    /* Transfer count */
    uint16_t               block_size;
                                /* Size of a block in block transfer mode */
    uint16_t               rsv;              /* Reserve bit */
    dtc_write_back_t       writeback_disable;
                                /* Transfer information writeback is enabled or not */
    dtc_sequence_end_t     sequence_end;
                                /* Sequence transfer is continued or end */
    dtc_refer_index_table_t refer_index_table_enable;
                                /* Index table reference is enabled or not */
    dtc_disp_add_t         disp_add_enable;
                                /* Displacement value is added to the source address or not */
} dtc_transfer_data_cfg_t;
```

2.11 Return Values

This section describes return values of API functions. This enumeration is located in `r_dtc_rx_if.h` as are the prototype declarations of API functions.

```
typedef enum e_dtc_err          /* DTC API error codes */
{
    DTC_SUCCESS_DMAC_BUSY = 0,
        /* One or some DMAC resources are locked by another process. */
    DTC_SUCCESS,
    DTC_ERR_OPENED,                /* DTC was initialized already. */
    DTC_ERR_NOT_OPEN,             /* DTC module is not initialized yet. */
    DTC_ERR_INVALID_ARG,         /* Arguments are invalid. */
    DTC_ERR_INVALID_COMMAND,     /* Command parameters are invalid. */
    DTC_ERR_NULL_PTR,           /* Argument pointers are NULL. */
    DTC_ERR_BUSY                /* The DTC resources are locked by another process. */
    DTC_ERR_ACT                  /* Data transfer is in progress */
} dtc_err_t;
```

2.12 Callback function

DTC FIT module don't use callback function.

2.13 Adding the FIT Module to Your Project

This module must be added to each project in which it is used. Renesas recommends the method using the Smart Configurator described in (1) or (3) below. However, the Smart Configurator only supports some RX devices. Please use the methods of (2) or (4) for RX devices that are not supported by the Smart Configurator.

- (1) Adding the FIT module to your project using the Smart Configurator in e² studio
By using the Smart Configurator in e² studio, the FIT module is automatically added to your project. Refer to “Renesas e² studio Smart Configurator User Guide (R20AN0451)” for details.
- (2) Adding the FIT module to your project using the FIT Configurator in e² studio
By using the FIT Configurator in e² studio, the FIT module is automatically added to your project. Refer to “Adding Firmware Integration Technology Modules to Projects (R01AN1723)” for details.
- (3) Adding the FIT module to your project using the Smart Configurator in CS+
By using the Smart Configurator Standalone version in CS+, the FIT module is automatically added to your project. Refer to “Renesas e² studio Smart Configurator User Guide (R20AN0451)” for details.
- (4) Adding the FIT module to your project in CS+
In CS+, please manually add the FIT module to your project. Refer to “Adding Firmware Integration Technology Modules to CS+ Projects (R01AN1826)” for details.

2.14 “for”, “while” and “do while” statements

In this module, “for”, “while” and “do while” statements (loop processing) are used in processing to wait for register to be reflected and so on. For these loop processing, comments with “WAIT_LOOP” as a keyword are described. Therefore, if user incorporates fail-safe processing into loop processing, user can search the corresponding processing with “WAIT_LOOP”.

The following shows example of description.

while statement example :

```
/* WAIT_LOOP */
while(0 == SYSTEM.OSCOVFSR.BIT.PLOVF)
{
    /* The delay period needed is to make sure that the PLL has stabilized. */
}
```

for statement example :

```
/* Initialize reference counters to 0. */
/* WAIT_LOOP */
for (i = 0; i < BSP_REG_PROTECT_TOTAL_ITEMS; i++)
{
    g_protect_counters[i] = 0;
}
```

do while statement example :

```
/* Reset completion waiting */
do
{
    reg = phy_read(ether_channel, PHY_REG_CONTROL);
    count++;
} while ((reg & PHY_CONTROL_RESET) && (count < ETHER_CFG_PHY_DELAY_RESET)); /* WAIT_LOOP */
```

3. API Functions

R_DTC_Open()

This function is run first when using the APIs of the DTC FIT module.

Format

dtc_err_t R_DTC_Open (void)

Parameters

None.

Return Values

[DTC_SUCCESS]	/* Successful operation */
[DTC_ERR_OPENED]	/* DTC has been initialized already. */
[DTC_ERR_BUSY]	/* Resource has been locked by other process. */

Properties

Prototype declarations are contained in r_dtc_rx_if.h.

Description

Locks*1 the DTC and starts supplying clock to DTC, then initializes DTC vector table, address mode, Data Transfer Read Skip. When setting DTC_CFG_DISABLE_ALL_ACT_SOURCE to DTC_ENABLE in r_dtc_rx_config.h, all DTCER registers are cleared. When setting DTC_CFG_USE_SEQUENCE_TRANSFER to DTC_ENABLE, the area used in DTC index table is secured.

Note: 1. The DTC FIT module uses the r_bsp default lock function. As a result, the DTC is in the locked state after a successful end.

Example

```
dtc_err_t ret;  
/* Call R_DTC_Open() */  
ret = R_DTC_Open();
```

Special Notes:

Set #define BSP_CFG_HEAP_BYTES in r_bsp_config.h to the value greater than #define DTC_VECTOR_TABLE_SIZE_BYTES in r_dtc_rx_target.h.

This is to secure the DTC Vector table area using the malloc() function in the DTC FIT module.

R_DTC_Close()

This function is used to release the resources of the DTC.

Format

dtc_err_t R_DTC_Close (void)

Parameters

None.

Return Values

[DTC_SUCCESS]

/ Successful operation */*

[DTC_SUCCESS_DMAC_BUSY]

/ Successful operation. One or some DMAC resources are locked. */*

Properties

Prototype declarations are contained in r_dtc_rx_if.h.

Description

Unlocks*¹ the DTC and disable all DTC activation source by clearing the DTC Activation Enable Register DTCERn; stop supplying clock to DTC and put it to Module stop state.

If in addition all DMAC channels have been unlocked, the function sets the DMAC and DTC to the module stop state.*²

- Note:
1. The DTC FIT module uses the r_bsp default lock function. As a result, the DTC is in the unlocked state after a successful end.
 2. Because a shared bit is used as both the DMAC module stop setting bit and the DTC module stop setting bit, the function confirms that all DMAC channels are unlocked before making the module stop setting. (For details, see the “Low Power Consumption” section in the User’s Manual: Hardware.

Change the processing method to match the combination of modules used, as shown below.

DMAC Control	DTC Control	Processing Method
DMACA FIT module (lock function control function present, DTC lock state checking function present)	DTC FIT module (lock function control function present, DMAC lock state checking function present)	See case 1.
Other than the above		See case 2.

Case 1: Using the r_bsp Default Lock Function and Controlling the DMAC with the DMAC FIT Module*¹

The function uses the r_bsp default lock function to confirm that all DMAC channels are unlocked and that the DTC is unlocked, then puts the DTC into the module stop state.

Note: 1. A necessary condition is that the DMAC FIT module has a module stop control function that confirms the locked state of the DTC.

Case 2: Control Other Than the Above

The user must provide code to confirm that all DMAC channels are unlocked and that the DTC is unlocked (not in use). The DTC FIT module includes an empty function for this purpose.

If the r_bsp default lock function is not used, insert the program code for checking the locked/unlocked state of all the DMAC channels and the DTC after the line marked */* do something */* in the r_dtc_check_DMAC_locking_byUSER() function in the file r_dtc_rx_target.c.

Note that bool type shown below should be used for the return value of the r_dtc_check_DMAC_locking_byUSER() function.

Returns value of r_dtc_check_DMAC_locking_byUSER()

<i>[true]</i>	<i>/* All DMAC channels are unlocked. */</i>
<i>[false]</i>	<i>/* One or some DMAC channels are locked. */</i>

Example

```
dtc_err_t ret;  
ret = R_DTC_Close();
```

Special Notes:

When controlling the DMAC without using the DMAC FIT module, make sure to monitor the usage of the DMAC and control locking and unlocking of the DMAC so that calling this function does not set the DMAC to the module stop state. Note that even if the DMAC has not been activated, it is necessary to keep it in the locked state when not making DMAC transfer settings.

R_DTC_Create()

This function is used to make DTC register settings and to specify the activation source.

Format

```

dtc_err_t      R_DTC_Create (
    dtc_activation_source_t act_source,
    dtc_transfer_data_t      *p_transfer_data,
    dtc_transfer_data_cfg_t *p_data_cfg,
    uint32_t                  chain_transfer_nr
)

```

Parameters

dtc_activation_source_t act_source

Activation source.

*dtc_transfer_data_t *p_transfer_data*

Pointer to start address of Transfer data area on RAM.

*dtc_transfer_data_cfg_t *p_data_cfg*

Pointer to settings for Transfer data

In the case of DTCb, the setting to the following structure members is invalid. This function sets the following values.

```

p_data_cfg->writeback_disable = DTC_WRITEBACK_ENABLE;
p_data_cfg->sequence_end     = DTC_SEQUENCE_TRANSFER_CONTINUE;
p_data_cfg->refer_index_table_enable = DTC_REFER_INDEX_TABLE_DISABLE;
p_data_cfg->disp_add_enable   = DTC_SRC_ADDR_DISP_ADD_DISABLE;

```

uint32_t chain_transfer_nr

Number of chain transfer

The number of Transfer data and corresponding configurations is (number of chain transfer + 1).

Example: if chain_transfer_nr = 1, it means that there are 2 continuous Transfer data and 2 corresponding configurations and the first configuration enable the chain transfer.

The type definition of a Transfer data (* p_transfer_data) depends on the address mode and the details are shown as below and the users will use this data type to allocate memory for Transfer data exactly:

```

#if (1 == DTC_CFG_SHORT_ADDRESS_MODE) /* Short address mode */
typedef struct st_transfer_data { /* 3 long words */
    uint32_t lw1;
    uint32_t lw2;
    uint32_t lw3;
} dtc_transfer_data_t;
#else /* Full-address mode */
typedef struct st_transfer_data { /* 4 long words */
    uint32_t lw1;
    uint32_t lw2;
    uint32_t lw3;
    uint32_t lw4;
} dtc_transfer_data_t;
#endif

```

The type of "Pointer to settings for Transfer data(* p_data_cfg)" is different by the DTC IP version. The data structure of configuration is below:

1. DTCa

```
typedef struct st_dtc_transfer_data_cfg {
    dtc_transfer_mode_t    transfer_mode;    /* DTC transfer mode */
    dtc_data_size_t        data_size;        /* Size of data */
    dtc_src_addr_mode_t    src_addr_mode;    /* Address mode of source */
    dtc_chain_transfer_t    chain_transfer_enable;
                                /* Chain transfer is enabled or not */
    dtc_chain_transfer_mode_t chain_transfer_mode;
                                /* How chain transfer is performed */
    dtc_interrupt_t        response_interrupt;
                                /* How response interrupt is raised */
    dtc_repeat_block_side_t repeat_block_side; /* Side being repeat or block */
    dtc_dest_addr_mode_t    dest_addr_mode;    /* Address mode of destination */
    uint32_t                source_addr;        /* Start address of source */
    uint32_t                dest_addr;    /* Start address of destination */
    uint32_t                transfer_count;    /* Transfer count */
    uint16_t                block_size;
                                /* Size of a block in block transfer mode */
    uint16_t                rsv;                /* Reserve bit */
} dtc_transfer_data_cfg_t;
```

2. DTCb

```
typedef struct st_dtc_transfer_data_cfg {
    dtc_transfer_mode_t    transfer_mode;    /* DTC transfer mode */
    dtc_data_size_t        data_size;        /* Size of data */
    dtc_src_addr_mode_t    src_addr_mode;    /* Address mode of source */
    dtc_chain_transfer_t    chain_transfer_enable;
                                /* Chain transfer is enabled or not */
    dtc_chain_transfer_mode_t chain_transfer_mode;
                                /* How chain transfer is performed */
    dtc_interrupt_t        response_interrupt;
                                /* How response interrupt is raised */
    dtc_repeat_block_side_t repeat_block_side; /* Side being repeat or block */
    dtc_dest_addr_mode_t    dest_addr_mode;    /* Address mode of destination */
    uint32_t                source_addr;        /* Start address of source */
    uint32_t                dest_addr;    /* Start address of destination */
    uint32_t                transfer_count;    /* Transfer count */
    uint16_t                block_size;
                                /* Size of a block in block transfer mode */
    uint16_t                rsv;                /* Reserve bit */
    dtc_write_back_t        writeback_disable;
                                /* Transfer information writeback is enabled or not */
    dtc_sequence_end_t        sequence_end;
                                /* Sequence transfer is continued or end */
    dtc_refer_index_table_t refer_index_table_enable;
                                /* Index table reference is enabled or not */
    dtc_disp_add_t          disp_add_enable;
                                /* Displacement value is added to the source address or not */
} dtc_transfer_data_cfg_t;
```


The following enumerate definitions indicate configurable options for above structures:

```

/* Configurable options for DTC Transfer mode */
typedef enum e_dtc_transfer_mode
{
    DTC_TRANSFER_MODE_NORMAL = (0),          /* = (0 << 6): Normal mode */
    DTC_TRANSFER_MODE_REPEAT = (1 << 6),     /* Repeat mode */
    DTC_TRANSFER_MODE_BLOCK  = (2 << 6),     /* Block mode */
} dtc_transfer_mode_t;

/* Configurable options for DTC Data transfer size */
typedef enum e_dtc_data_size
{
    DTC_DATA_SIZE_BYTE   = (0),              /* = (0 << 4): 8-bit (byte) data */
    DTC_DATA_SIZE_WORD   = (1 << 4),         /* 16-bit (word) data */
    DTC_DATA_SIZE_LWORD  = (2 << 4),         /* 32-bit (long word) data */
} dtc_data_size_t;

/* Configurable options for Source address addressing mode */
typedef enum e_dtc_src_addr_mode
{
    DTC_SRC_ADDR_FIXED = (0),                /* = (0 << 2): Source address is fixed. */
    DTC_SRC_ADDR_INCR  = (2 << 2),           /* Source address is incremented after each transfer. */
    DTC_SRC_ADDR_DECR  = (3 << 2),           /* Source address is decremented after each transfer. */
} dtc_src_addr_mode_t;

/* Configurable options for Chain transfer */
typedef enum e_dtc_chain_transfer
{
    DTC_CHAIN_TRANSFER_DISABLE = (0),        /* Disable Chain transfer. */
    DTC_CHAIN_TRANSFER_ENABLE  = (1 << 7),   /* Enable Chain transfer. */
} dtc_chain_transfer_t;

/* Configurable options for how chain transfer is performed */
typedef enum e_dtc_chain_transfer_mode
{
    DTC_CHAIN_TRANSFER_CONTINUOUSLY = (0),    /* = (0 << 6): Chain transfer is performed continuously. */
    DTC_CHAIN_TRANSFER_NORMAL       = (1 << 6)
}
/* Chain transfer is performed only when the counter is changed to 0 or CRAH. */
} dtc_chain_transfer_mode_t;

/* Configurable options for Interrupt */
typedef enum e_dtc_interrupt
{
    DTC_INTERRUPT_AFTER_ALL_COMPLETE = (0),
    /* Interrupt is generated when specified data transfer is completed. */
    DTC_INTERRUPT_PER_SINGLE_TRANSFER = (1 << 5)
    /* Interrupt is generated when each transfer time is completed. */
} dtc_interrupt_t;

/* Configurable options for Side to be repeat or block */
typedef enum e_dtc_repeat_block_side
{
    DTC_REPEAT_BLOCK_DESTINATION = (0),
    /* = (0 << 4): Destination is repeat or block area. */
    DTC_REPEAT_BLOCK_SOURCE      = (1 << 4)
    /* Source is repeat or block area. */
} dtc_repeat_block_side_t;

```

```

/* Configurable options for Destination address addressing mode */
typedef enum e_dtc_dest_addr_mode
{
    DTC_DES_ADDR_FIXED = (1 << 2), /* Destination address is fixed. */
    DTC_DES_ADDR_INCR  = (2 << 2), /* Destination address is incremented after each transfer. */
    DTC_DES_ADDR_DECR  = (3 << 2)  /* Destination address is decremented after each transfer. */
} dtc_dest_addr_mode_t;

/* Configurable options to write back transfer information */
typedef enum e_dtc_write_back
{
    DTC_WRITEBACK_ENABLE  = (0), /* Writeback is enabled */
    DTC_WRITEBACK_DISABLE = (1)  /* Writeback is disabled */
} dtc_write_back_t;

/* Configurable option to continue/end sequence transfer */
typedef enum e_dtc_sequence_end
{
    DTC_SEQUENCE_TRANSFER_CONTINUE = (0), /* Sequence transfer is continued */
    DTC_SEQUENCE_TRANSFER_END      = (1)  /* Sequence transfer is ended */
} dtc_sequence_end_t;

/* Configurable options for index table reference */
typedef enum e_dtc_refer_index_table
{
    DTC_REFER_INDEX_TABLE_DISABLE = (0), /* Index table is not referred */
    DTC_REFER_INDEX_TABLE_ENABLE  = (1 << 1) /* Index table is referred */
} dtc_refer_index_table_t;

/* Configurable options to add/not to add Displacement value to the destination
address */
typedef enum e_dtc_disp_add
{
    DTC_SRC_ADDR_DISP_ADD_DISABLE = (0), /* Displacement value is not added to the source address */
    DTC_SRC_ADDR_DISP_ADD_ENABLE  = (1)  /* Displacement value is added to the source address */
} dtc_disp_add_t;

```

The transfer_count is set from 1 to 65536 in Normal transfer mode and Block transfer mode, from 1 to 256 in Repeat transfer mode.

The block_size value is set from 1 to 256 in Block transfer mode.

In short address mode, the start address of Transfer data (second argument), source area and destination area is in range (0x00000000 to 0x007FFFFFFF and 0xFF800000 to 0xFFFFFFFF).

Return Values

<code>[DTC_SUCCESS]</code>	<i>/* Successful operation */</i>
<code>[DTC_ERR_NOT_OPEN]</code>	<i>/* DTC is not initialized yet. */</i>
<code>[DTC_ERR_INVALID_ARG]</code>	<i>/* Parameters are invalid. */</i>
<code>[DTC_ERR_NULL_PTR]</code>	<i>/* Argument pointers are NULL. */</i>

Properties

Prototype declarations are contained in `r_dtc_rx_if.h`.

Description

Writes the configuration to Transfer data.

Writes the start address of Transfer data corresponding to interrupt number into DTC vector table.

Example**Case 1: In the case of No chain transfer**

```

dtc_transfer_data_cfg_t td_cfg;
dtc_activation_source_t act_src = DTCE_ICU_SWINT; /* activation source is
Software Interrupt */

dtc_transfer_data_t transfer_data; /* assume that DTC address mode is full
mode */

dtc_err_t ret;
uint32_t src = 1234;
uint32_t des[3];
uint8_t ien_bk;

/* create the configuration - no chain transfer */
/* Source address addressing mode is FIXED
 * Data size is 32 bits (long word)
 * DTC transfer mode is Repeat mode & Source side is repeat area
 * Interrupt is raised after each single transfer
 * Chain transfer is disabled
 */
td_cfg.src_addr_mode      = DTC_SRC_ADDR_FIXED;
td_cfg.data_size          = DTC_DATA_SIZE_LWORD;
td_cfg.transfer_mode      = DTC_TRANSFER_MODE_REPEAT;
td_cfg.dest_addr_mode     = DTC_DEST_ADDR_INCR;
td_cfg.repeat_block_side  = DTC_REPEAT_BLOCK_SOURCE;
td_cfg.response_interrupt = DTC_INTERRUPT_PER_SINGLE_TRANSFER;
td_cfg.chain_transfer_enable = DTC_CHAIN_TRANSFER_DISABLE;
td_cfg.chain_transfer_mode = (dtc_chain_transfer_mode_t)0;

td_cfg.source_addr        = (uint32_t)&src;
td_cfg.dest_addr          = (uint32_t)des;
td_cfg.transfer_count     = 1;
td_cfg.block_size         = 3;

/* Disable Software interrupt request before calling R_DTC_Create() */
ien_bk = ICU.IER[3].BIT.IEN3 ; /* store old setting */
ICU.IER[3].BIT.IEN3 = 0;

/* Calling to R_DTC_Create() */

ret = R_DTC_Create(act_src, &transfer_data, &td_cfg, 0);

```

```
/* Restore the setting for Software interrupt request */
ICU.IER[3].BIT.IEN3 = ien_bk;
```

Case 2: In the case of ONE chain transfer

```
dtc_transfer_data_cfg_t td_cfg[2]; /* need 2 configuration sets */
dtc_activation_source_t act_src = DTCE_ICU_SWINT;
/* activation source is Software Interrupt */
uint32_t transfer_data[8];
/* for 2 Transfer data; assume that DTC address mode is full mode */
dtc_err_t ret;
uint32_t src = 1234;
uint32_t des[3]; /* The destination for first Transfer data */
uint32_t des2[3]; /* The destination for second Transfer data */
uint8_t ien_bk;

/* create the configuration 1 - support chain transfer */
/* Source address addressing mode is FIXED
 * Destination address addressing mode is INCREMENTED
 * Data size is 32 bits (long word)
 * DTC transfer mode is Normal mode
 * Interrupt is raised after each single transfer
 * Chain transfer is enabled
 * Chain transfer is performed after when transfer counter is set to 0
 */
td_cfg[0].src_addr_mode = DTC_SRC_ADDR_FIXED;
td_cfg[0].data_size = DTC_DATA_SIZE_LWORD;
td_cfg[0].transfer_mode = DTC_TRANSFER_MODE_NORMAL;
td_cfg[0].dest_addr_mode = DTC_DES_ADDR_INCR;
td_cfg[0].repeat_block_side = DTC_REPEAT_BLOCK_SOURCE;
td_cfg[0].response_interrupt = DTC_INTERRUPT_PER_SINGLE_TRANSFER;
td_cfg[0].chain_transfer_enable = DTC_CHAIN_TRANSFER_ENABLE;
td_cfg[0].chain_transfer_mode = DTC_CHAIN_TRANSFER_NORMAL;

td_cfg[0].source_addr = (uint32_t)&src;
td_cfg[0].dest_addr = (uint32_t)des; /* transfer from source to des 1 */
td_cfg[0].transfer_count = 1;
td_cfg[0].block_size = 3;

/* create the configuration 2 - no chain transfer */
/* Source address addressing mode is FIXED
 * Destination address addressing mode is INCREMENTED
 * Data size is 32 bits (long word)
 * DTC transfer mode is Normal mode
 * Interrupt is raised after each single transfer
 * Chain transfer is disabled
 */
td_cfg[1].src_addr_mode = DTC_SRC_ADDR_FIXED;
td_cfg[1].data_size = DTC_DATA_SIZE_LWORD;
td_cfg[1].transfer_mode = DTC_TRANSFER_MODE_NORMAL;
td_cfg[1].dest_addr_mode = DTC_DES_ADDR_INCR;
td_cfg[1].repeat_block_side = DTC_REPEAT_BLOCK_SOURCE;
td_cfg[1].response_interrupt = DTC_INTERRUPT_PER_SINGLE_TRANSFER;
td_cfg[1].chain_transfer_enable = DTC_CHAIN_TRANSFER_DISABLE;
td_cfg[1].chain_transfer_mode = (dtc_chain_transfer_mode_t)0;

td_cfg[1].source_addr = (uint32_t)&src;
td_cfg[1].dest_addr = (uint32_t)des2; /* transfer from source to des 2 */
td_cfg[1].transfer_count = 1;
td_cfg[1].block_size = 3;
/* Disable Software interrupt request before calling R_DTC_Create() */
```

```

ien_bk = ICU.IER[3].BIT.IEN3 ; /* store old setting */
ICU.IER[3].BIT.IEN3 = 0;

/* Call R_DTC_Create() */
ret = R_DTC_Create(act_src, transfer_data , td_cfg, 1); /* The fourth argument
indicates that there's one chain transfer enabled in first Transfer data */

/* Restore the setting for Software interrupt request */
ICU.IER[3].BIT.IEN3 = ien_bk;

```

Case 3: In the case of multiple source registration

```

dtc_transfer_data_cfg_t td_cfg_sw;
dtc_transfer_data_cfg_t td_cfg_cmt;
dtc_activation_source_t act_src_sw = DTCE_ICU_SWINT;
/* activation source is Software Interrupt */
dtc_activation_source_t act_src_cmt = DTCE_CMT0_CMI0;
/* activation source is CMT Interrupt */
dtc_transfer_data_t transfer_data_sw;
/* assume that DTC address mode is full mode */
dtc_transfer_data_t transfer_data_cmt;
/* assume that DTC address mode is full mode */

dtc_err_t ret;
uint32_t src_sw = 1234;
uint32_t src_cmt = 5678;
uint32_t des_sw[3];
uint32_t des_cmt[3];
uint8_t ien_bk;

/* create the configuration - no chain transfer */
/* Source address addressing mode is FIXED
* Data size is 32 bits (long word)
* DTC transfer mode is Repeat mode & Source side is repeat area
* Interrupt is raised after each single transfer
* Chain transfer is disabled
*/
td_cfg_sw.src_addr_mode = DTC_SRC_ADDR_FIXED;
td_cfg_sw.data_size = DTC_DATA_SIZE_LWORD;
td_cfg_sw.transfer_mode = DTC_TRANSFER_MODE_REPEAT;
td_cfg_sw.dest_addr_mode = DTC_DEST_ADDR_INCR;
td_cfg_sw.repeat_block_side = DTC_REPEAT_BLOCK_SOURCE;
td_cfg_sw.response_interrupt = DTC_INTERRUPT_PER_SINGLE_TRANSFER;
td_cfg_sw.chain_transfer_enable = DTC_CHAIN_TRANSFER_DISABLE;
td_cfg_sw.chain_transfer_mode = (dtc_chain_transfer_mode_t)0;

td_cfg_sw.source_addr = (uint32_t)&src_sw;
td_cfg_sw.dest_addr = (uint32_t)&des_sw;
td_cfg_sw.transfer_count = 1;
td_cfg_sw.block_size = 3;

/* Disable Software interrupt request before calling R_DTC_Create() */
ien_bk = ICU.IER[3].BIT.IEN3 ; /* store old setting */
ICU.IER[3].BIT.IEN3 = 0;

```

```

/* Calling to R_DTC_Create() */
ret = R_DTC_Create(act_src_sw, &transfer_data_sw, &td_cfg_sw, 0);
/* Restore the setting for Software interrupt request */
ICU.IER[3].BIT.IEN3 = ien_bk;

/* create the configuration - no chain transfer */
/* Source address addressing mode is FIXED
* Data size is 32 bits (long word)
* DTC transfer mode is Repeat mode & Source side is repeat area
* Interrupt is raised after each single transfer
* Chain transfer is disabled
*/
td_cfg_cmt.src_addr_mode = DTC_SRC_ADDR_FIXED;
td_cfg_cmt.data_size = DTC_DATA_SIZE_LWORD;
td_cfg_cmt.transfer_mode = DTC_TRANSFER_MODE_REPEAT;
td_cfg_cmt.dest_addr_mode = DTC_DEST_ADDR_INCR;
td_cfg_cmt.repeat_block_side = DTC_REPEAT_BLOCK_SOURCE;
td_cfg_cmt.response_interrupt = DTC_INTERRUPT_PER_SINGLE_TRANSFER;
td_cfg_cmt.chain_transfer_enable = DTC_CHAIN_TRANSFER_DISABLE;
td_cfg_cmt.chain_transfer_mode = (dtc_chain_transfer_mode_t)0;

td_cfg_cmt.source_addr = (uint32_t)&src_cmt;
td_cfg_cmt.dest_addr = (uint32_t)&des_cmt;
td_cfg_cmt.transfer_count = 1;
td_cfg_cmt.block_size = 3;

/* Calling to R_DTC_Create() */
ret = R_DTC_Create(act_src_cmt, &transfer_data_cmt, &td_cfg_cmt, 0);

R_CMT_CreateOneShot(10000, &cmt_callback, &cmt_channel);

```

Special Notes:

Before calling R_DTC_Create(), user must disable the current interrupt request (the interrupt source is passed to R_DTC_Create()) by clearing Interrupt Request Enable bit IERm.IENj:

```
ICU.IER[m].BIT.IENj = 0;
```

Then, enable the interrupt request disabled after R_DTC_Create() is ended.

The correspondence between IERm.IENj bit and interrupt source is described in Interrupt Vector Table, chapter Interrupt Controller (ICU) of User's Manual: Hardware.

R_DTC_CreateSeq()

This function performs the setting of the DTC register used in the sequence transfer and the activation source.

Format

```
dtc_err_t R_DTC_CreateSeq(
    dtc_activation_source_t act_source,
    dtc_transfer_data_t *p_transfer_data,
    dtc_transfer_data_cfg_t *p_data_cfg,
    uint32_t sequence_transfer_nr,
    uint8_t sequence_no)
)
```

Parameters

act_source

Activation source

**p_transfer_data*

Pointer to the start address in the transfer information area in RAM.

**p_data_cfg*

Pointer to the transfer information setting

Set the following structure members.

```
p_data_cfg->writeback_disable
p_data_cfg->sequence_end
p_data_cfg->refer_index_table_enable
p_data_cfg->disp_add_enable
```

sequence_transfer_nr

Transfer information counts per sequence transfer (0 - 4294967295)

sequence_transfer_nr	Description
0	When transfer request for the sequence number (sequence_no) specified is generated, the setting is made to output CPU interrupt request without starting the sequence.
1 - 4294967295	When transfer request for the sequence number (sequence_no) specified is generated, the transfer information for the sequence transfer is set. Prepare transfer information about the number to be specified sequence_transfer_nr in advance, and set the start address of the transfer information to *p_data_cfg.

sequence_no

Sequence number (0 - 255)

The type definition of the transfer information and the data structure are the same as R_DTC_Create(). Total of 256 ways of the sequence information can be set.

Return Values

<code>DTC_SUCCESS</code>	<i>/* Successful operation */</i>
<code>DTC_ERR_NOT_OPEN</code>	<i>/* DTC is not initialized yet. */</i>
<code>DTC_ERR_INVALID_ARG</code>	<i>/* Arguments are invalid. */</i>
<code>DTC_ERR_NULL_PTR</code>	<i>/* Argument pointers are NULL. */</i>

Properties

Prototype declarations are contained in `r_dtc_rx_if.h`.

Description

This function writes the setting information to the transfer information.

Start address of the transfer information for the sequence number is written to DTC index table.

Example

Examples of asynchronous serial receiving by the sequence transfer based on the Receive FIFO Full Interrupt (RXI) as DTC activation source is explained as follows. SCI used is Channel 10. Sequence transfer is automatically started according to 1 bit data (cmdnd) received first from external communication device.

Case 1:

After receiving cmdnd= "00h" from external communication device, SCI10 receive FIFO threshold is changed to 4 bytes, then, 4 bytes data output from external communication device is received, and is stored in the RAM by DTC transfer.

Table 3-1 Transfer information specified in Case 1

Member	Transfer information 1	Transfer information 2	Transfer information 3
transfer_mode	Normal transfer	Block transfer	Normal transfer
data_size	8 bits	16 bits	8 bits
src_addr_mode	Fix source address	Fix source address	Fix source address
chain_transfer_enable	Disable chain transfer	Enable chain transfer	Disable chain transfer
chain_transfer_mode	Perform chain transfer continuously (setting disabled)	Perform chain transfer continuously	Perform chain transfer continuously (setting disabled)
response_interrupt	Generate interrupt after the specified data transfer is complete.	Generate interrupt after the specified data transfer is complete.	Generate interrupt after the specified data transfer is complete.
repeat_block_side	Destination is repeat or block area (setting disabled)	Destination is repeat or block area	Destination is repeat or block area (setting disabled)
dest_addr_mode	Fix destination address	Increment destination Address per transfer	Fix destination address
source_addr	ROM dtc_fcrh_data[0] Address	SCI10.FRDR register address	ROM g_dtc_fcrh_cmdnd address
dest_addr	SCI10.FCR.H register Address	RAM g_dtc_rx_buf0[0] address	SCI10.FCR.H register address
transfer_count	1	1	1
block_size	(Setting disabled)	4	(Setting disabled)
writeback_disable	No write back	No write back	No write back
sequence_end	Continue sequence transfer	Continue sequence transfer	End sequence transfer
refer_index_table_enable	Not refer to index table	Not refer to index table	Not refer to index table
disp_add_enable	Not add Displacement value to the source address	Not add Displacement value to the source address	Not add Displacement value to the source address

```

#include "platform.h"
#include "r_dtc_rx_if.h"

#define CMND0_RCV_NUM (4)
#define CMND0_RCV_FIFO_TRG (4)
#define CMND0_FCRH_DATA ((uint8_t)(0xF0 | CMND0_RCV_FIFO_TRG))
#define CMND0_INFO_NUM (3)

dtc_transfer_data_cfg_t g_dtc_pre_seqinfo_cmnd0[CMND0_INFO_NUM];
dtc_transfer_data_t g_dtc_seqinfo_cmnd0[CMND0_INFO_NUM];
uint16_t g_dtc_rx_buf0[CMND0_RCV_NUM];
const uint8_t g_dtc_fcrh_cmnd = 0xF1;
static const uint8_t dtc_fcrh_data[] =
{
    CMND0_FCRH_DATA,
    CMND1_FCRH_DATA,
    CMND2_FCRH_DATA,
    CMND3_FCRH_DATA
};

void dtc_pre_seqinfo_cmnd0_init(void);

void main(void)
{
    dtc_err_t ret;
    dtc_activation_source_t act_source;
    uint32_t sequence_transfer_nr;
    uint8_t sequence_no;
    uint8_t ien_bk;

    ...

    /* ---- DTC sequence transfer information for Cmnd0 ---- */
    dtc_pre_seqinfo_cmnd0_init();
    act_source = DTCE_SCI10_RXI10;
    sequence_transfer_nr = CMND0_INFO_NUM;
    sequence_no = 0;
    ien_bk = IEN(SCI10,RXI10); /* IEN(x,x)->ICU.IER[z].BIT.IENz; */
    IEN(SCI10,RXI10) = 0;
    ret = R_DTC_CreateSeq(act_source,
                          &g_dtc_seqinfo_cmnd0[0],
                          &g_dtc_pre_seqinfo_cmnd0[0],
                          sequence_transfer_nr,
                          sequence_no);
    IEN(SCI10,RXI10)= ien_bk;

    ...
}

void dtc_pre_seqinfo_cmnd0_init(void)
{
    /* [1st] Sequence transfer information -
       Changing the SCI10 Receive FIFO trigger */
    /* MRA */
    g_dtc_pre_seqinfo_cmnd0[0].transfer_mode = DTC_TRANSFER_MODE_NORMAL;
    g_dtc_pre_seqinfo_cmnd0[0].data_size = DTC_DATA_SIZE_BYTE;
    g_dtc_pre_seqinfo_cmnd0[0].src_addr_mode = DTC_SRC_ADDR_FIXED;
    g_dtc_pre_seqinfo_cmnd0[0].writeback_disable = DTC_WRITEBACK_DISABLE;
    /* MRB */
    g_dtc_pre_seqinfo_cmnd0[0].chain_transfer_enable =
        DTC_CHAIN_TRANSFER_DISABLE;
}

```

```

g_dtc_pre_seqinfo_cmnd0[0].chain_transfer_mode =
    DTC_CHAIN_TRANSFER_CONTINUOUSLY;
g_dtc_pre_seqinfo_cmnd0[0].response_interrupt =
    DTC_INTERRUPT_AFTER_ALL_COMPLETE;
g_dtc_pre_seqinfo_cmnd0[0].repeat_block_side =
    DTC_REPEAT_BLOCK_DESTINATION;
g_dtc_pre_seqinfo_cmnd0[0].dest_addr_mode = DTC_DEST_ADDR_FIXED;
g_dtc_pre_seqinfo_cmnd0[0].refer_index_table_enable =
    DTC_REFER_INDEX_TABLE_DISABLE;
g_dtc_pre_seqinfo_cmnd0[0].sequence_end =
    DTC_SEQUENCE_TRANSFER_CONTINUE;
/* MRC */
g_dtc_pre_seqinfo_cmnd0[0].disp_add_enable =
    DTC_SRC_ADDR_DISP_ADD_DISABLE;
/* SAR */
g_dtc_pre_seqinfo_cmnd0[0].source_addr = (uint32_t)&dtc_fcrh_data[0];
/* DAR */
g_dtc_pre_seqinfo_cmnd0[0].dest_addr = (uint32_t)&SCI10.FCR.BYTE.H;
/* CRA, CRB */
g_dtc_pre_seqinfo_cmnd0[0].transfer_count = 1;

/* [2nd] Sequence transfer information -
    transfers the received data from SCI10.FRDR to RAM */
/* MRA */
g_dtc_pre_seqinfo_cmnd0[1].transfer_mode = DTC_TRANSFER_MODE_BLOCK;
g_dtc_pre_seqinfo_cmnd0[1].data_size = DTC_DATA_SIZE_WORD;
g_dtc_pre_seqinfo_cmnd0[1].src_addr_mode = DTC_SRC_ADDR_FIXED;
g_dtc_pre_seqinfo_cmnd0[1].writeback_disable = DTC_WRITEBACK_DISABLE;
/* MRB */
g_dtc_pre_seqinfo_cmnd0[1].chain_transfer_enable =
    DTC_CHAIN_TRANSFER_ENABLE;
g_dtc_pre_seqinfo_cmnd0[1].chain_transfer_mode =
    DTC_CHAIN_TRANSFER_CONTINUOUSLY;
g_dtc_pre_seqinfo_cmnd0[1].response_interrupt =
    DTC_INTERRUPT_AFTER_ALL_COMPLETE;
g_dtc_pre_seqinfo_cmnd0[1].repeat_block_side =
    DTC_REPEAT_BLOCK_DESTINATION;
g_dtc_pre_seqinfo_cmnd0[1].dest_addr_mode = DTC_DEST_ADDR_INCR;
g_dtc_pre_seqinfo_cmnd0[1].refer_index_table_enable =
    DTC_REFER_INDEX_TABLE_DISABLE;
g_dtc_pre_seqinfo_cmnd0[1].sequence_end =
    DTC_SEQUENCE_TRANSFER_CONTINUE;
/* MRC */
g_dtc_pre_seqinfo_cmnd0[1].disp_add_enable = DTC_SRC_ADDR_DISP_ADD_DISABLE;
/* SAR */
g_dtc_pre_seqinfo_cmnd0[1].source_addr = (uint32_t)&SCI10.FRDR.WORD;
/* DAR */
g_dtc_pre_seqinfo_cmnd0[1].dest_addr = (uint32_t)&g_dtc_rx_buf0[0];
/* CRA, CRB */
g_dtc_pre_seqinfo_cmnd0[1].transfer_count = 1;
g_dtc_pre_seqinfo_cmnd0[1].block_size = CMND0_RCV_FIFO_TRG;

/* [3rd] Sequence transfer information -
    Changing the SCI10 Receive FIFO trigger to 1 */
/* MRA */
g_dtc_pre_seqinfo_cmnd0[2].transfer_mode = DTC_TRANSFER_MODE_NORMAL;
g_dtc_pre_seqinfo_cmnd0[2].data_size = DTC_DATA_SIZE_BYTE;
g_dtc_pre_seqinfo_cmnd0[2].src_addr_mode = DTC_SRC_ADDR_FIXED;
g_dtc_pre_seqinfo_cmnd0[2].writeback_disable = DTC_WRITEBACK_DISABLE;
/* MRB */

```

```

g_dtc_pre_seqinfo_cmnd0[2].chain_transfer_enable =
                                DTC_CHAIN_TRANSFER_DISABLE;
g_dtc_pre_seqinfo_cmnd0[2].chain_transfer_mode =
                                DTC_CHAIN_TRANSFER_CONTINUOUSLY;
g_dtc_pre_seqinfo_cmnd0[2].response_interrupt =
                                DTC_INTERRUPT_AFTER_ALL_COMPLETE;
g_dtc_pre_seqinfo_cmnd0[2].repeat_block_side =
                                DTC_REPEAT_BLOCK_DESTINATION;
g_dtc_pre_seqinfo_cmnd0[2].dest_addr_mode = DTC_DES_ADDR_FIXED;
g_dtc_pre_seqinfo_cmnd0[2].refer_index_table_enable=
                                DTC_REFER_INDEX_TABLE_DISABLE;
g_dtc_pre_seqinfo_cmnd0[2].sequence_end = DTC_SEQUENCE_TRANSFER_END;
/* MRC */
g_dtc_pre_seqinfo_cmnd0[2].disp_add_enable =DTC_SRC_ADDR_DISP_ADD_DISABLE;
/* SAR */
g_dtc_pre_seqinfo_cmnd0[2].source_addr = (uint32_t)&g_dtc_fcrh_cmnd;
/* DAR */
g_dtc_pre_seqinfo_cmnd0[2].dest_addr = (uint32_t)&SCI10.FCR.BYTE.H;
/* CRA, CRB */
g_dtc_pre_seqinfo_cmnd0[2].transfer_count = 1;
}

```

Case 2 :

When receiving cmnd >= "04h" from external communication device, generate the interrupt to CPU without sequence transfer.

```

#include "platform.h"
#include "r_dtc_rx_if.h"

void main(void)
{
    dtc_err_t ret;
    dtc_activation_source_t act_source;
    uint32_t sequence_transfer_nr;
    uint8_t sequence_no;
    uint8_t ien_bk;
    uint16_t i;

    ...

    /* ---- DTC sequence transfer information for Cmnd4-Cmnd255 ---- */
    for (i = 4; i < 256; i++)
    {
        act_source = DTCE_SCI10_RXI10;
        sequence_transfer_nr = 0;
        sequence_no = i;
        ien_bk = IEN(SCI10,RXI10); /* IEN(x,x)->ICU.IER[z].BIT.IENz; */
        IEN(SCI10,RXI10) = 0;
        ret = R_DTC_CreateSeq(act_source,
                                NULL,
                                NULL,
                                sequence_transfer_nr,
                                sequence_no);
        IEN(SCI10,RXI10) = ien_bk;
    }

    ...
}

```

Special Notes:

Before calling R_DTC_CreateSeq(), user must disable the current interrupt request (the interrupt source is passed to R_DTC_CreateSeq()) by clearing Interrupt Request Enable bit (IERm.IENj):

```
ICU.IER[m].BIT.IENj = 0;
```

Then, enable the interrupt request disabled after R_DTC_CreateSeq() is ended.

The correspondence between IERm.IENj bit and interrupt source is described in Interrupt Vector Table, chapter Interrupt Controller (ICU) of User's Manual: Hardware.

R_DTC_Control()

This function controls the operation of the DTC.

Format

```

dtc_err_t    R_DTC_Control (
                dtc_command_t    command,
                dtc_stat_t        *p_stat,
                dtc_cmd_arg_t     *p_args
            )

```

Parameters

dtc_command_t command
DTC control command

*dtc_stat_t *p_stat*
Pointer to the status when command is DTC_CMD_STATUS_GET.

Member of *dtc_stat_t* Structure

Member	Short Description	Setting Value	Setting Details
vect_nr	DTC-Activating Vector Number	Vector Number Monitoring	The value is only valid when DTC transfer is in progress (the value of the DTC Active Flag is 1).
in_progress	DTC Active Flag	- false - true	- DTC transfer operation is not in progress. - DTC transfer operation is in progress.

*dtc_cmd_arg_t *p_args*
Pointer to the argument structure when command is *DTC_CMD_ACT_SRC_ENABLE*, *DTC_CMD_ACT_SRC_DISABLE*, *DTC_CMD_CHAIN_TRANSFER_ABORT*, *DTC_CMD_SEQUENCE_TRANSFER_ENABLE*, or *DTC_CMD_CHANGING_DATA_FORCIBLY_SET*.

Members of *dtc_cmd_arg_t* Structure

Member	Short Description	Setting Details
act_src	DTC-Activating Vector Number	The value is only valid when command is <i>DTC_CMD_ACT_SRC_ENABLE</i> or <i>DTC_CMD_ACT_SRC_DISABLE</i> or <i>DTC_CMD_SEQUENCE_TRANSFER_ENABLE</i> or <i>DTC_CMD_CHANGING_DATA_FORCIBLY_SET</i>
chain_transfer_nr	Number of chain transfer (Note)	The value is only valid when command is <i>DTC_CMD_CHAIN_TRANSFER_ABORT</i> or <i>DTC_CMD_CHANGING_DATA_FORCIBLY_SET</i> .
*p_transfer_data	Pointer to start address of Transfer data area on RAM	The value is only valid when command is <i>DTC_CMD_CHANGING_DATA_FORCIBLY_SET</i> .
*p_data_cfg	Pointer to settings for Transfer data	The value is only valid when command is <i>DTC_CMD_CHANGING_DATA_FORCIBLY_SET</i> .

Note: Set the value as same as the argument *chain_transfer_nr* when user call *R_DTC_Create()* before.

Return Values

```

[DTC_SUCCESS]           /* Successful operation */
[DTC_ERR_NOT_OPEN]      /* DTC is not initialized yet. */
[DTC_ERR_INVALID_COMMAND] /* Command parameters are invalid or
                        DTC_CMD_CHANGING_DATA_FORCIBLY_SET command error. */
[DTC_ERR_NULL_PTR]      /* Argument pointers are NULL. */
[DTC_ERR_ACT]           /* Data transfer is in progress. */

```

Properties

Prototype declarations are contained in r_dtc_rx_if.h.

Description

Processing is performed depending on the command.

Command	Arguments dtc_stat_t *	Arguments dtc_cmd_arg_t *	Description
DTC_CMD_DTC_START	NULL	NULL	Starts DTC module using DTC Module Start (DTCST) bit.
DTC_CMD_DTC_STOP	NULL	NULL	Stops DTC module using DTC Module Start (DTCST) bit.
DTC_CMD_DATA_READ_SKIP_ENABLE	NULL	NULL	Enables Transfer Data Read Skip using DTC Transfer Information Read Skip Enable (RRS) bit.
DTC_CMD_DATA_READ_SKIP_DISABLE	NULL	NULL	Disables Transfer Data Read Skip using DTC Transfer Information Read Skip Enable (RRS) bit.
DTC_CMD_ACT_SRC_ENABLE	NULL	p_args->act_src	Sets an interrupt source using DTC Start Enable (DTCE) bit.
DTC_CMD_ACT_SRC_DISABLE	NULL	p_args->act_src	Clears an interrupt source using DTC Start Enable (DTCE) bit.
DTC_CMD_STATUS_GET	p_stat->in_progress p_stat->vect_nr	NULL	Gets a DTC Active Flag (ACT) and vector number (VECN[7:0]) using DTC Status Register (DTCSTS).
DTC_CMD_CHAIN_TRANSFER_ABORT	NULL	p_args->chain_transfer_nr	Aborts the current active chain transfer.
DTC_CMD_SEQUENCE_TRANSFER_ENABLE	NULL	p_args->act_src	Specifies Sequence Transfer Vector number and enables Sequence transfer using DTC Sequence Transfer Enable Register (DTCSEQ).
DTC_CMD_SEQUENCE_TRANSFER_DISABLE	NULL	NULL	Disables Sequence Transfer using DTC Sequence Transfer Enable Register (DTCSEQ).
DTC_CMD_SEQUENCE_TRANSFER_ABORT	NULL	NULL	Aborts Sequence Transfer using Sequence Transfer End bit (SQTFRL).
DTC_CMD_CHANGING_DATA_FORCIBLY_SET	NULL	p_args->act_src p_args->chain_transfer_nr p_args->p_transfer_data p_args->p_data_cfg	Changes the value set by R_DTC_Create(). It is a valid process for changing parameters*1 forcibly set by R_DTC_Create().

Note: 1.writeback_disable, sequence_end, refer_index_table_enable, and disp_add_enable

Example**Case 1: Start DTC module**

```
dtc_err_t ret;

/* Start DTC module */
ret = R_DTC_Control(DTC_CMD_DTC_START, NULL, NULL);
```

Case 2: Stop DTC module

```
dtc_err_t ret;

/* Stop DTC module */
ret = R_DTC_Control(DTC_CMD_DTC_STOP, NULL, NULL);
```

Case 3 : Enable transfer information read skip

```
dtc_err_t ret;

/* Enable transfer information read skip */
ret = R_DTC_Control(DTC_CMD_DATA_READ_SKIP_ENABLE, NULL, NULL);
```

Case 4: Disable transfer information read skip

```
dtc_err_t ret;

/* Disable transfer information read skip */
ret = R_DTC_Control(DTC_CMD_DATA_READ_SKIP_DISABLE, NULL, NULL);
```

Case 5 : Using the DTCE, set the interrupt used for DTC activation source

```
dtc_err_t ret;
dtc_cmd_arg_t args;

/* Disable DTC transfer request by SCI10 receive data full interrupt */
IEN(SCI10, RXI10) = 0;

/* Set SCI10 receive data full interrupt as DTC activation source*/
args.act_src = DTCE_SCI10_RXI10;

/* Set the interrupt used for DTC activation source */
ret = R_DTC_Control(DTC_CMD_ACT_SRC_ENABLE, NULL, &args);
```

Case 6 : Using the DTCE, clear the interrupt used for DTC activation source

```
dtc_err_t ret;
dtc_cmd_arg_t args;

/* Disable DTC transfer request by SCI10 receive data full interrupt */
IEN(SCI10, RXI10) = 0;

/* Set SCI10 receive data full interrupt as DTC activation source */
args.act_src = DTCE_SCI10_RXI10;

/* Delete the interrupt used for DTC activation source */
ret = R_DTC_Control(DTC_CMD_ACT_SRC_DISABLE, NULL, &args);
```


Case 7 : Get DTC Active Flag (ACT) and Vector number (VECN[7:0]) in progress

```
dtc_err_t ret;
dtc_stat_t stat;
uint8_t interrupt_number;

/* Get DTC Active Flag (ACT) and Vector number(VECN[7:0])in progress */
ret = R_DTC_Control(DTC_CMD_STATUS_GET, stat, NULL);

if (true == stat.in_progress)
{
    /* Vector number is valid */
    interrupt_number = stat.vect_nr;
}
else
{
    /* Vector number is inbalid */
}
```

Case 8 : Abort the chain transfer in process

```
dtc_err_t ret;
dtc_cmd_arg_t args;

/* No. Of chain transfer = 5 */
args.chain_transfer_nr = 5;

/* Abort the chain transfer in process */
ret = R_DTC_Control(DTC_CMD_STATUS_GET, NULL, &args);
```

Case 9 : Enable the sequence transfer

```
dtc_err_t ret;
dtc_cmd_arg_t args;

/* Set SCI10 receive data full interrupt as sequence transfger activation source */
args.act_src = DTCE_SCI10_RXI10;

/* Enable sequence transfer */
ret = R_DTC_Control(DTC_CMD_SEQUENCE_TRANSFER_ENABLE, NULL, &args);
```

Case 10: Disable the sequence transfer

```
dtc_err_t ret;

/* Disable sequence transfer */
ret = R_DTC_Control(DTC_CMD_SEQUENCE_TRANSFER_DISABLE, NULL, NULL);
```

Case 11: Abort the sequence transfer

```
dtc_err_t ret;

/* Disable DTC transfer request by SCI10 receive data full interrupt */
IEN(SCI10, RXI10) = 0;

/* Issue command repeatedly until sequence transfer can be aborted */
do
{
    ret = R_DTC_Control(DTC_CMD_SEQUENCE_TRANSFER_ABORT, NULL, NULL);
} while (DTC_ERR_ACT == ret);
```

Case 12: Changes the value set by R_DTC_Create()

```

dtd_activation_source_t act_source;
uint32_t chain_transfer_nr;

act_source = DTCE_SCI10_RXI10;
chain_transfer_nr = 0;
if (R_DTC_Create(act_source,
                 &g_dtc_info_sqnum,
                 &g_dtc_pre_info_sqnum,
                 chain_transfer_nr) != DTC_SUCCESS)
{
    /* Error */
}

g_dtc_pre_info_sqnum.writeback_disable = DTC_WRITEBACK_DISABLE;
g_dtc_pre_info_sqnum.sequence_end     = DTC_SEQUENCE_TRANSFER_CONTINUE;
g_dtc_pre_info_sqnum.refer_index_table_enable = DTC_REFER_INDEX_TABLE_ENABLE;
g_dtc_pre_info_sqnum.disp_add_enable   = DTC_SRC_ADDR_DISP_ADD_DISABLE;
args.act_src = DTCE_SCI10_RXI10;
args.chain_transfer_nr = 0;
args.p_transfer_data = &g_dtc_info_sqnum;
args.p_data_cfg = &g_dtc_pre_info_sqnum;
if (R_DTC_Control(DTC_CMD_CHANGING_DATA_FORCIBLY_SET, NULL, &args) !=
DTC_SUCCESS)
{
    /* Error */
}

```

Special Notes:

When the command is DTC_CMD_GET_STATUS, the vector number is valid if only the DTC is in the progress (p_stat->in_progress is true).

With command DTC_CMD_ENABLE_ACT_SRC, DTC_CMD_DISABLE_ACT_SRC or DTC_CMD_SEQUENCE_TRANSFER_ABORT, before calling R_DTC_Control(), user must disable the current interrupt request (the interrupt source is passed to R_DTC_Control()) by clearing Interrupt Request Enable bit (IERm.IENj);

```
ICU.IER[m].BIT.IENj = 0;
```

After processing of R_DTC_Control() is ended, the interrupt request disabled is enabled.

The correspondence between IERm.IENj bit and interrupt source is described in Interrupt Vector Table, chapter Interrupt Controller (ICU) of User's Manual: Hardware.

With abort processing, user must re-create the Chain transfer data after the transfer is aborted because the old Transfer data are destroyed.

If an invalid value is attempted to set with DTC_CMD_CHANGING_DATA_FORCIBLY_SET, R_DTC_Control() returns DTC_ERR_INVALID_COMMAND

R_DTC_Control() may already update some registers before the invalid value is detected. This occurs only when users try to change FORCIBLY DTC with Invalid Value.

R_DTC_GetVersion()

This function is used to get the driver version information.

Format

uint32_t R_DTC_GetVersion (void)

Parameters

None.

Return Values

Version number

Upper 2 bytes: major version, lower 2 bytes: minor version

Properties

Prototype declarations are contained in r_dtc_rx_if.h.

Description

Returns the version information.

Example

```
uint32_t version;  
version = R_DTC_GetVersion();
```

Special Notes:

None.

4. Pin Setting

DTC FIT module don't use pin setting.

5. Demo Projects

Demo projects include function main() that utilizes the FIT module and its dependent modules (e.g. r_bsp). This FIT module includes the following demo projects.

5.1 dtc_demo_rskrx231, dtc_demo_rskrx231_gcc

The dtc_demo_rskrx231, dtc_demo_rskrx231_gcc program demonstrates how to set up a DTC in repeat transfer mode to handle ADC conversion result. As the program runs, the DTC save ADC conversion result to a buffer of 32 bytes in sequence.

5.2 dtc_demo_rskrx65n_2m, dtc_demo_rskrx65n_2m_gcc

The dtc_demo_rskrx65n_2m, dtc_demo_rskrx65n_2m_gcc program is identical to dtc_demo_rskrx231.

5.3 dtc_demo_rskrx130, dtc_demo_rskrx130_gcc

The dtc_demo_rskrx130, dtc_demo_rskrx130_gcc program is identical to dtc_demo_rskrx231.

5.4 dtc_demo_rskrx72m, dtc_demo_rskrx72m_gcc

The dtc_demo_rskrx72m, dtc_demo_rskrx72m_gcc program is identical to dtc_demo_rskrx231.

5.5 dtc_demo_rskrx671, dtc_demo_rskrx671_gcc

The dtc_demo_rskrx671, dtc_demo_rskrx671_gcc program is identical to dtc_demo_rskrx231.

5.6 Adding a Demo to a Workspace

Demo projects are found in the FITDemos subdirectory of the distribution file for this application note. To add a demo project to a workspace, select *File >> Import >> General >> Existing Projects* into Workspace, then click "Next". From the Import Projects dialog, choose the "Select archive file" radio button. "Browse" to the FITDemos subdirectory, select the desired demo zip file, then click "Finish".

5.7 Downloading Demo Projects

Demo projects are not included in the RX Driver Package. When using the demo project, the FIT module needs to be downloaded. To download the FIT module, right click on this application note and select "Sample Code (download)" from the context menu in the *Smart Browser >> Application Notes* tab.

6. Appendices

6.1 Confirmed Operation Environment

This section describes confirmed operation environment for the DTC FIT module.

Table 6.1 Confirmed Operation Environment (Rev.3.90)

Item	Contents
Integrated development environment	Renesas Electronics e ² studio Version 2021-07 IAR Embedded Workbench for Renesas RX 4.20.3
C compiler	Renesas Electronics C/C++ Compiler Package for RX Family V3.03.00 Compiler option: The following option is added to the default settings of the integrated development environment. -lang = c99 GCC for Renesas RX 8.3.0.202004 Compiler option: The following option is added to the default settings of the integrated development environment. -std=gnu99 Linker option: The following user defined option should be added to the default settings of the integrated development environment, if "Optimize size (-Os)" is used: -Wl,--no-gc-sections This is to work around a GCC linker issue whereby the linker erroneously discard interrupt functions declared in FIT peripheral module IAR C/C++ Compiler for Renesas RX version 4.20.3 Compiler option: The default settings of the integrated development environment.
Endian	Big endian/little endian
Revision of the module	Rev.3.90
Board used	Renesas Starter Kit+ for RX671 (product No.: RTK55671xxxxxxxxxx)

Table 6.2 Confirmed Operation Environment (Rev.3.80)

Item	Contents
Integrated development environment	Renesas Electronics e ² studio Version 2021-07 IAR Embedded Workbench for Renesas RX 4.20.3
C compiler	Renesas Electronics C/C++ Compiler Package for RX Family V3.03.00 Compiler option: The following option is added to the default settings of the integrated development environment. -lang = c99 GCC for Renesas RX 8.3.0.202004 Compiler option: The following option is added to the default settings of the integrated development environment. -std=gnu99 Linker option: The following user defined option should be added to the default settings of the integrated development environment, if "Optimize size (-Os)" is used: -Wl,--no-gc-sections This is to work around a GCC linker issue whereby the linker erroneously discard interrupt functions declared in FIT peripheral module IAR C/C++ Compiler for Renesas RX version 4.20.3 Compiler option: The default settings of the integrated development environment.
Endian	Big endian/little endian
Revision of the module	Rev.3.80
Board used	Target board for RX140 (Part Number.: RTK5RX140xxxxxxxxxx)

Table 6.3 Confirmed Operation Environment (Rev.3.70)

Item	Contents
Integrated development environment	Renesas Electronics e ² studio Version 2021-07 IAR Embedded Workbench for Renesas RX 4.20.3
C compiler	Renesas Electronics C/C++ Compiler Package for RX Family V3.03.00 Compiler option: The following option is added to the default settings of the integrated development environment. -lang = c99 GCC for Renesas RX 8.3.0.202004 Compiler option: The following option is added to the default settings of the integrated development environment. -std=gnu99 Linker option: The following user defined option should be added to the default settings of the integrated development environment, if "Optimize size (-Os)" is used: -Wl,--no-gc-sections This is to work around a GCC linker issue whereby the linker erroneously discard interrupt functions declared in FIT peripheral module IAR C/C++ Compiler for Renesas RX version 4.20.3 Compiler option: The default settings of the integrated development environment.
Endian	Big endian/little endian
Revision of the module	Rev.3.70
Board used	Renesas Starter Kit+ for RX671 (product No.: RTK55671xxxxxxxxxx)

Table 6.4 Confirmed Operation Environment (Rev.3.60)

Item	Contents
Integrated development environment	Renesas Electronics e ² studio Version 7.8.0
C compiler	Renesas Electronics C/C++ Compiler Package for RX Family V3.02.00 Compiler option: The following option is added to the default settings of the integrated development environment. -lang = c99 GCC for Renesas RX 8.3.0.201904 Compiler option: The following option is added to the default settings of the integrated development environment. -std=gnu99 Linker option: The following user defined option should be added to the default settings of the integrated development environment, if "Optimize size (-Os)" is used: -Wl,--no-gc-sections This is to work around a GCC linker issue whereby the linker erroneously discard interrupt functions declared in FIT peripheral module
Endian	Little endian
Revision of the module	Rev.3.60
Board used	Renesas Starter Kit+ for RX72M (product No.: RTK5572Mxxxxxxxxxx) Renesas Starter Kit+ for RX65N-2MB (product No.: RTK50565N2CxxxxxBR) Renesas Starter Kit for RX130 (product No.: RTK5005130SxxxxxBE) Renesas Starter Kit+ for RX231 (product No.: RTK505231xxxxxxxxxx)

Table 6.5 Confirmed Operation Environment (Rev.3.50)

Item	Contents
Integrated development environment	Renesas Electronics e ² studio Version 7.7.0 IAR Embedded Workbench for Renesas RX 4.12.1
C compiler	Renesas Electronics C/C++ Compiler Package for RX Family V3.02.00 Compiler option: The following option is added to the default settings of the integrated development environment. -lang = c99 GCC for Renesas RX 8.3.0.201904 Compiler option: The following option is added to the default settings of the integrated development environment. -std=gnu99 Linker option: The following user defined option should be added to the default settings of the integrated development environment, if "Optimize size (-Os)" is used: -Wl,--no-gc-sections This is to work around a GCC linker issue whereby the linker erroneously discard interrupt functions declared in FIT peripheral module IAR C/C++ Compiler for Renesas RX version 4.12.1 Compiler option: The default settings of the integrated development environment.
Endian	Big endian/little endian
Revision of the module	Rev.3.50
Board used	Renesas Solution Starter Kit+ for RX23E-A (product No.: RTK0ESXBxxxxxxxxxx)

Table 6.6 Confirmed Operation Environment (Rev.3.40)

Item	Contents
Integrated development environment	Renesas Electronics e ² studio Version 7.7.0 IAR Embedded Workbench for Renesas RX 4.12.1
C compiler	Renesas Electronics C/C++ Compiler Package for RX Family V3.01.00 Compiler option: The following option is added to the default settings of the integrated development environment. -lang = c99 GCC for Renesas RX 4.8.4.201902 Compiler option: The following option is added to the default settings of the integrated development environment. -std=gnu99 Linker option: The following user defined option should be added to the default settings of the integrated development environment, if "Optimize size (-Os)" is used: -Wl,--no-gc-sections This is to work around a GCC linker issue whereby the linker erroneously discard interrupt functions declared in FIT peripheral module IAR C/C++ Compiler for Renesas RX version 4.12.1 Compiler option: The default settings of the integrated development environment.
Endian	Big endian/little endian
Revision of the module	Rev.3.40
Board used	Renesas Starter Kit+ for RX72N (product No.: RTK5572Nxxxxxxxxxx)

Table 6.7 Confirmed Operation Environment (Rev.3.30)

Item	Contents
Integrated development environment	Renesas Electronics e ² studio Version 7.7.0
C compiler	<p>Renesas Electronics C/C++ Compiler Package for RX Family V3.01.00 Compiler option: The following option is added to the default settings of the integrated development environment. -lang = c99</p> <p>GCC for Renesas RX 4.8.4.201902 Compiler option: The following option is added to the default settings of the integrated development environment. -std=gnu99 Linker option: The following user defined option should be added to the default settings of the integrated development environment, if "Optimize size (-Os)" is used: -Wl,--no-gc-sections This is to work around a GCC linker issue whereby the linker erroneously discard interrupt functions declared in FIT peripheral module</p>
Endian	Big endian/little endian
Revision of the module	Rev.3.30
Board used	RX13T CPU Card (product No.: RTK0EMXA10C00000BJ)

Table 6.8 Confirmed Operation Environment (Rev.3.21)

Item	Contents
Integrated development environment	<p>Renesas Electronics e² studio Version 7.5.0 IAR Embedded Workbench for Renesas RX 4.12.1</p>
C compiler	<p>Renesas Electronics C/C++ Compiler Package for RX Family V3.01.00 Compiler option: The following option is added to the default settings of the integrated development environment. -lang = c99</p> <p>GCC for Renesas RX 4.8.4.201902 Compiler option: The following option is added to the default settings of the integrated development environment. -std=gnu99 Linker option: The following user defined option should be added to the default settings of the integrated development environment, if "Optimize size (-Os)" is used: -Wl,--no-gc-sections This is to work around a GCC linker issue whereby the linker erroneously discard interrupt functions declared in FIT peripheral module</p> <p>IAR C/C++ Compiler for Renesas RX version 4.12.1 Compiler option: The default settings of the integrated development environment.</p>
Endian	Big endian/little endian
Revision of the module	Rev.3.21
Board used	Renesas Solution Starter Kit for RX23W (product No.: RTK5523Wxxxxxxxxxx)

Table 6.9 Confirmed Operation Environment (Rev.3.20)

Item	Contents
Integrated development environment	Renesas Electronics e ² studio Version 7.5.0 IAR Embedded Workbench for Renesas RX 4.12.1
C compiler	Renesas Electronics C/C++ Compiler Package for RX Family V3.01.00 Compiler option: The following option is added to the default settings of the integrated development environment. -lang = c99 GCC for Renesas RX 4.8.4.201902 Compiler option: The following option is added to the default settings of the integrated development environment. -std=gnu99 Linker option: The following user defined option should be added to the default settings of the integrated development environment, if "Optimize size (-Os)" is used: -Wl,--no-gc-sections This is to work around a GCC linker issue whereby the linker erroneously discard interrupt functions declared in FIT peripheral module IAR C/C++ Compiler for Renesas RX version 4.12.1 Compiler option: The default settings of the integrated development environment.
Endian	Big endian/little endian
Revision of the module	Rev.3.20
Board used	Renesas Starter Kit+ for RX72M (product No.: RTK5572Mxxxxxxxxxx)

Table 6.10 Confirmed Operation Environment (Rev.3.10)

Item	Contents
Integrated development environment	Renesas Electronics e ² studio Version 7.5.0
C compiler	Renesas Electronics C/C++ Compiler Package for RX Family V3.01.00 Compiler option: The following option is added to the default settings of the integrated development environment. -lang = c99
Endian	Big endian/little endian
Revision of the module	Rev.3.10
Board used	Renesas Solution Starter Kit for RX23W (product No.: RTK5523Wxxxxxxxxxx)

Table 6.11 Confirmed Operation Environment (Rev.3.01)

Item	Contents
Integrated development environment	Renesas Electronics e ² studio Version 7.4.0 IAR Embedded Workbench for Renesas RX 4.10.1
C compiler	Renesas Electronics C/C++ Compiler Package for RX Family V3.01.00 Compiler option: The following option is added to the default settings of the integrated development environment. -lang = c99 GCC for Renesas RX 4.8.4.201803 Compiler option: The following option is added to the default settings of the integrated development environment. -std=gnu99 Linker option: The following user defined option should be added to the default settings of the integrated development environment, if "Optimize size (-Os)" is used: -Wl,--no-gc-sections This is to work around a GCC linker issue whereby the linker erroneously discard interrupt functions declared in FIT peripheral module IAR C/C++ Compiler for Renesas RX version 4.10.1 Compiler option: The default settings of the integrated development environment.
Endian	Big endian/little endian
Revision of the module	Rev.3.01
Board used	Renesas Starter Kit+ for RX65N-2MB (product No.: RTK50565Nxxxxxxxxx)

Table 6.12 Confirmed Operation Environment (Rev.3.00)

Item	Contents
Integrated development environment	Renesas Electronics e ² studio Version 7.4.0 IAR Embedded Workbench for Renesas RX 4.10.1
C compiler	Renesas Electronics C/C++ Compiler Package for RX Family V3.01.00 Compiler option: The following option is added to the default settings of the integrated development environment. -lang = c99 GCC for Renesas RX 4.8.4.201803 Compiler option: The following option is added to the default settings of the integrated development environment. -std=gnu99 Linker option: The following user defined option should be added to the default settings of the integrated development environment, if "Optimize size (-Os)" is used: -Wl,--no-gc-sections This is to work around a GCC linker issue whereby the linker erroneously discard interrupt functions declared in FIT peripheral module IAR C/C++ Compiler for Renesas RX version 4.10.1 Compiler option: The default settings of the integrated development environment.
Endian	Big endian/little endian
Revision of the module	Rev.3.00
Board used	Renesas Starter Kit+ for RX65N-2MB (product No.: RTK50565Nxxxxxxxxx)

Table 6.13 Confirmed Operation Environment (Rev.2.20)

Item	Contents
Integrated development environment	Renesas Electronics e2 studio V7.3.0
C compiler	Renesas Electronics C/C++ compiler for RX Family V3.01.00 Compiler options: The integrated development environment default settings are used, with the following option added. -lang = c99
Endian order	Big-endian/Little-endian
Module version	Ver.2.20
Board used	Renesas Starter Kit for RX72T (product No.: RTK5572Txxxxxxxxxx)

Table 6.14 Confirmed Operation Environment (Rev.2.10)

Item	Contents
Integrated development environment	Renesas Electronics e2 studio V7.0.0
C compiler	Renesas Electronics C/C++ compiler for RX Family V3.00.00 Compiler options: The integrated development environment default settings are used, with the following option added. -lang = c99
Endian order	Big-endian/Little-endian
Module version	Ver.2.10
Board used	Renesas Starter Kit for RX111 (product No.: R0K505111SxxxBE) Renesas Starter Kit for RX113 (product No.: R0K505113SxxxBE) Renesas Starter Kit for RX130 (product No.: RTK5005130SxxxxxxBE) Renesas Starter Kit for RX130-512KB (product No.: RTK5051308SxxxxxxBE) Renesas Starter Kit for RX231 (product No.: R0K505231SxxxBE) Renesas Starter Kit for RX23T (product No.: RTK500523TSxxxxxxBE) Renesas Starter Kit for RX24T (product No.: RTK500524TSxxxxxxBE) Renesas Starter Kit for RX24U (product No.: RTK500524USxxxxxxBE) Renesas Starter Kit for RX64M (product No.: R0K50564MSxxxBE) Renesas Starter Kit for RX71M (product No.: R0K50571MSxxxBE) Renesas Starter Kit for RX65N (product No.: RTK500565NSxxxxxxBE) Renesas Starter Kit for RX65N-2MB (product No.: RTK50565N2SxxxxxxBE) Renesas Starter Kit for RX66T (product No.: RTK50566T0SxxxxxxBE)

Table 6.15 Confirmed Operation Environment (Rev.2.08)

Item	Contents
Integrated development environment	Renesas Electronics e2 studio V6.0.0
C compiler	Renesas Electronics C/C++ compiler for RX Family V.2.07.00 Compiler options: The integrated development environment default settings are used, with the following option added. -lang = c99
Endian order	Big-endian/Little-endian
Module version	Ver.2.08
Board used	Renesas Starter Kit for RX111 (product No.: R0K505111SxxxBE) Renesas Starter Kit for RX113 (product No.: R0K505113SxxxBE) Renesas Starter Kit for RX130 (product No.: RTK5005130SxxxxxBE) Renesas Starter Kit for RX130-512KB (product No.: RTK5051308SxxxxxBE) Renesas Starter Kit for RX231 (product No.: R0K505231SxxxBE) Renesas Starter Kit for RX23T (product No.: RTK500523TSxxxxxBE) Renesas Starter Kit for RX24T (product No.: RTK500524TSxxxxxBE) Renesas Starter Kit for RX24U (product No.: RTK500524USxxxxxBE) Renesas Starter Kit for RX64M (product No.: R0K50564MSxxxBE) Renesas Starter Kit for RX71M (product No.: R0K50571MSxxxBE) Renesas Starter Kit for RX65N (product No.: RTK500565NSxxxxxBE) Renesas Starter Kit for RX65N-2MB (product No.: RTK50565N2SxxxxxBE)

6.2 Troubleshooting

(1) Q: I have added the FIT module to the project and built it. Then I got the error: Could not open source file "platform.h".

A: The FIT module may not be added to the project properly. Check if the method for adding FIT modules is correct with the following documents:

- Using CS+:

Application note "Adding Firmware Integration Technology Modules to CS+ Projects (R01AN1826)"

- Using e² studio:

Application note "Adding Firmware Integration Technology Modules to Projects (R01AN1723)"

When using this FIT module, the board support package FIT module (BSP module) must also be added to the project. Refer to the application note "Board Support Package Module Using Firmware Integration Technology (R01AN1685)".

(2) Q: I have added the FIT module to the project and built it. Then I got the error: This MCU is not supported by the current r_dtc_rx module.

A: The FIT module you added may not support the target device chosen in your project. Check the supported devices of added FIT modules.

7. Reference Documents

User's Manual: Hardware

The latest versions can be downloaded from the Renesas Electronics website.

Technical Update/Technical News

The latest information can be downloaded from the Renesas Electronics website.

User's Manual: Development Tools

RX Family C/C++ Compiler CC-RX User's Manual (R20UT3248)

The latest version can be downloaded from the Renesas Electronics website.

Related Technical Updates

Not applicable technical update for this module.

Revision History

Rev.	Date	Description	
		Page	Summary
2.02	Apr 1, 2015	—	First edition issued
2.03	Jun 15, 2015	1	Added RX230 Group and RX231 Group In Target Device
		9	1.2.2 Operating Environment and Memory Size
			Added (5)RX231
		18	3.2 R_DTC_Close() Description
2.04	Dec 29, 2015		Changed “If all DMAC channels are unlocked,” to “If all DMAC channels have been unlocked,”
		27	3.3 R_DTC_Create()
			Added Case 3: In the case of multiple source registration to Example
		1	Added RX130 Group, RX23T Group, and RX24T Group In Target Device
2.05	Sep 30, 2016	2	Changed the explanation of 1. Overviews;
			“The DTC is activated by interrupt.....start the transfer.”
		13	2.6 Compile Settings #define
			DTC_CFG_SHORT_ADDRESS_MODE
			Changed from “ADDRRESS”
		14	2.7 Arguments
			Added /* Short-address mode */ and /* Full-address mode */
		16	Updated 2.9 Adding Driver to Your Project
		20	3.3 R_DTC_Create() Parameters
			#if (1 == DTC_CFG_SHORT_ADDRESS_MODE)
			Changed from “ADDRRESS”
		25	3.3 R_DTC_Create() Example Case 1
			Added uint8_t ien_bk;
			Changed from dest_addr to des_addr
		26	3.3 R_DTC_Create() Example Case 2
			Changed from uint32 transfer_data[8] to uint32_t transfer_data[8]
			Added uint8_t ien_bk;
		26	3.3 R_DTC_Create() Example Case 2
			Changed from dest_addr to des_addr (2 places)
		27	3.3 R_DTC_Create() Example Case 3
			Added uint8_t ien_bk;
			Changed from dest_addr to des_addr
		27	3.3 R_DTC_Create() Example Case 3
			Changed from dest_addr to des_addr :
		30	3.4 R_DTC_Control() Example
			Added uint8_t interrupt_number;
2.05	Sep 30, 2016	1	Added RX65N Group In Target Device
		2-3	Added the contents of sequence transfer to 1. Overview
		4	1.2.1 Overview of API
			Added “R_DTC_CreateSeq()” to Table 1.1
		10	1.2.2 Operating Environment and Memory Size
2.05	Sep 30, 2016		Added (6)RX65N
		12	2.1 Hardware Requirements
2.05	Sep 30, 2016		Added DTCb

2.05	Sep 30, 2016	13	2.6 Compile Settings Added "#define DTC_CFG_USE_SEQUENCE_TRANSFER to the table
		14	2.7 Arguments Added r_dtc_rx_target_if.h
		14-15	Divided the contents of 2.7 Arguments into 2.7.1 r_dtc_rx_if.h and 2.7.2 r_dtc_rx_target_if.h
		15	2.7.1 r_dtc_rx_if.h Added Structure dtc_command_t to the followings; DTC_CMD_SEQUENCE_TRANSFER_ENABLE DTC_CMD_SEQUENCE_TRANSFER_DISABLE DTC_CMD_SEQUENCE_TRANSFER_ABORT
		16	2.8 Return Values Added DTC_ERR_ACT
		16	2.9 Adding FIT Module to Your Project Changed the title from Adding Driver to Your Project
		17	3.1 R_DTC_Open() Added the contents of Description DTC Index table
		21	3.3 R_DTC_Create() Added the contents of DTCb to Data structure dtc_transfer_data_cfg_t
		23	3.3 R_DTC_Create() Added the following data structure; dtc_write_back_t, dtc_sequence_end_t, dtc_refer_index_table_t, dtc_disp_add_t
		29 - 34	Added 3.4 R_DTC_CreateSeq()
		35	3.5 R_DTC_Control() Return Values Added DTC_ERR_ACT
		36	3.5 R_DTC_Control() Description Added the table
		37 -39	3.5 R_DTC_Control() Revised the contents of Example
2.06	Jan 31, 2017	10	1.2.2 Operating Environment and Memory Size Updated Table 1.12 and Table 1.13.
		20 - 21	3.3 R_DTC_Create() Parameters Added the explanation.
		29	3.4 R_DTC_CreateSeq() Parameters Added the explanation.
2.07	Mar 31, 2017	-	Changed the following chapter number. Moved 1.2.2 Operating Environment and Memory Sizes to 2.3 Operating Environment, 2.8 Code Size and 4.1 Details of Operating Environment.
		1	Added RX24U Group in Target Device
		4	Added 1.3. DTC IP Version.
		5	1.4 Related Application Note Revised the contents
		37	Added 4. Appendix
		-	Moved the following chapter contents. Moved from 1. Overview to 1.2 Overview of APIs Changed the following chapter number. Changed form 2.3 Operating Environment to 5.1 Operating Confirmation environment Changed form 4. Appendix to 5.Appendices Changed form 5. Reference Documents to 6. Reference
2.08	Jul 31, 2017	-	

			Documents
			Added the following chapter.
			Added 2.4 Interrupt vector usage
			Added 2.12 Adding FIT Module to your Project
			Added 5.2 Troubleshooting
		1	Added RX651 Group in Target Device
		7	Deleted "r_cgc_rx" of 2.2 Software Requirements.
		31 - 35	3.5 R_DTC_Control()
			Added new command
			"DTC_CMD_CHANGING_DATA_FORCIBLY_SET".
2.10	Sep 28, 2018	1,5	Added support for RX66T.
		8	Added code size corresponding to RX66T
		40	5.1 Confirmed Operation Environment:
			Added Table for Rev.2.10
2.20	Feb 01, 2019	1	Added RX72T Group in Target Device
		5	Added RX72T Group to DTC IP version section
		9	Added code size corresponding to RX72T
		16-39	Removed 'Reentrant' description in each API function.
		38	Updated Special notes of R_DTC_Control() function
		41	Changed Renesas Starter Kit for RX66T Product No
		41	6.1 Confirmed Operation Environment:
			Added Table for Rev.2.20
3.00	May.20.19	—	Supported the following compilers:
			- GCC for Renesas RX
			- IAR C/C++ Compiler for Renesas RX
		1	Added the section of Target compilers.
			Deleted related documents.
		6	2.2 Software Requirements
			Requires r_bsp v5.20 or higher
		9	Updated the section of 2.8 Code Size
		41	Table 5.1 Confirmed Operation Environment:
			Added table for Rev.3.00
		44	Deleted the section of Website and Support.
3.01	Jun.18.19	—	Removed "defined(__BIG_ENDIAN__)" from
			DTC_BIG_ENDIAN macro definition.
3.10	Jun.28.19	1, 5	Added support for RX23W
		9	Added code size corresponding to RX23W
		41	Added 5. Demo Projects
		42	6.1 Confirmed Operation Environment:
			Added Table for Rev.3.10
3.20	Aug.15.19	1, 5	Added support for RX72M
		10	Added code size corresponding to RX72M
		42	Table 6.1: Confirmed Operation Environment:
			Added Table for Rev.3.20
			Table 6.2: Corrected board name for RX23W
		Program	Added support for RX72M.

3.21	Nov.12.19	42	Table 6.1: Confirmed Operation Environment: Added Table for Rev.3.21
		Program	Removed some macros in r_dtc_rx_target.c for RX23W
3.30	Nov.25.19	1, 5	Added support for RX13T
		6	2.3 Limitations Added limitations.
		11	Added code size corresponding to RX13T
		43	Table 6.1: Confirmed Operation Environment: Added Table for Rev.3.30
		Program	Added support for RX13T. Changed the comment of API functions to the doxygen style.
3.40	Dec.30.19	1, 5	Added support for RX66N, RX72N
		10-11	Added code size corresponding to RX66N, RX72N
		44	Table 6.1: Confirmed Operation Environment: Added Table for Rev.3.40
		Program	Added support for RX66N, RX72N.
3.50	Mar.31.20	1, 6	Added support for RX23E-A
		11	Added code size corresponding to RX23E-A
		45	Table 6.1: Confirmed Operation Environment: Added Table for Rev.3.50
		Program	Added support for RX23E-A.
3.60	Jun.30.20	44	Updated and added new demo project Added RSKRX72M to "5. Demo Projects".
		45	Table 6.1: Confirmed Operation Environment: Added Table for Rev.3.60
		Program	Updated and added new demo project
3.70	Mar.31.21	1, 7	Added support for RX671
		6	Added 1.3 Using the FIT DTC module. Added 1.3.1 Using FIT DTC module in C++ project.
		14	Added code size corresponding to RX671
		45	Table 6.1: Confirm Operation Environment: Added Table for Rev. 3.70
		Program	Added support for RX671.
3.80	Apr.15.21	1, 7	Added support for RX140
		14	Added code size corresponding to RX140
		45	Table 6.1: Confirm Operation Environment: Added Table for Rev. 3.80
		Program	Added support for RX140. Added CS+ support for demo project. Updated configuration settings for all demo projects
3.90	Sep.13.21	44	Added "5.5 dtc_demo_rskrx671, dtc_demo_rskrx671_gcc"
		45	Table 6.1: Confirm Operation Environment: Added Table for Rev. 3.90.
		Program	Updated and added new demo projects

General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Precaution against Electrostatic Discharge (ESD)

A strong electrical field, when exposed to a CMOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop the generation of static electricity as much as possible, and quickly dissipate it when it occurs. Environmental control must be adequate. When it is dry, a humidifier should be used. This is recommended to avoid using insulators that can easily build up static electricity. Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors must be grounded. The operator must also be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions must be taken for printed circuit boards with mounted semiconductor devices.

2. Processing at power-on

The state of the product is undefined at the time when power is supplied. The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the time when power is supplied. In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the time when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the time when power is supplied until the power reaches the level at which resetting is specified.

3. Input of signal during power-off state

Do not input signals or an I/O pull-up power supply while the device is powered off. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Follow the guideline for input signal during power-off state as described in your product documentation.

4. Handling of unused pins

Handle unused pins in accordance with the directions given under handling of unused pins in the manual. The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of the LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible.

5. Clock signals

After applying a reset, only release the reset line after the operating clock signal becomes stable. When switching the clock signal during program execution, wait until the target clock signal is stabilized. When the clock signal is generated with an external resonator or from an external oscillator during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Additionally, when switching to a clock signal produced with an external resonator or by an external oscillator while program execution is in progress, wait until the target clock signal is stable.

6. Voltage application waveform at input pin

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between V_{IL} (Max.) and V_{IH} (Min.) due to noise, for example, the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between V_{IL} (Max.) and V_{IH} (Min.).

7. Prohibition of access to reserved addresses

Access to reserved addresses is prohibited. The reserved addresses are provided for possible future expansion of functions. Do not access these addresses as the correct operation of the LSI is not guaranteed.

8. Differences between products

Before changing from one product to another, for example to a product with a different part number, confirm that the change will not lead to problems. The characteristics of a microprocessing unit or microcontroller unit products in the same group but having a different part number might differ in terms of internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
6. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
10. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
11. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.4.0-1 November 2017)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,
Koto-ku, Tokyo 135-0061, Japan
www.renesas.com

Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:
www.renesas.com/contact/

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.